MA0/1 DUCT SERIES DRAIN PUMP INSTALLATION MANUAL

■ Drain pump Fitting List

DB68-03726A(2)

- Drain pamp r ital	.9 =.01			DD00 001 201 1(2)
Drain Pump(1)	Plug(1)	Sponge Sealing	Heat Insulation	Flexible
Drain Fullip(1)	Flug(1)	Strips(1)	Protection	Drainage
Float Switch(1)	Drain Hose(1)	Cover drain pump(1)		
res.	(

■ Drain pump Installation Steps

	allation Steps	
Installation Manual	Installation Step	Installation Schematic Diagram
	1-1 Assemble the drain pump using screws. (Drain pump, plate cover comp and Switch float) Note: Make sure the drain pump direction is right as you seen in the picture. (Distance A:58.5mm;Distance B:56.5mm)	A
Drain pump Installation	1-2 Remove the Control Cover. Through the Hole,remove the wire from PCB.Then remover the Control Box. 1-3 Remove the part as seen in the picture using the right tools. 1-4 Install and connect the drain hose. Note: Make the drain rubber pipe tightly with the Pump Motor and add a cable tie so that it does not get removed.	Drin hose

Installation Manual	Installation Step	Installation Schematic Diagram
Drain pump Installation	1-5 Assemble the Drain Kit. Assemble the Drain hose.	
Wire Connection and Swith Setting	2-1 Drain pump wire connection. The port of the drain pump boday connection wire is yellow. The port of float switch connection wire is black. 2-2-1 Setting an indoor unit installation option (SEG 8) 2-2-2 Drain pump(SEG8) will be set to 'Disuse' 'Use' and 'USE+3minutes delay'. Note: Option is defined as follows. 0.Disuse 1.Use 2.When an indoor unit stops, drain pump will operate for 3 minutes. 2-3 Bundle up the drain pump connection wire.	SAME SUND

Installation Manual	Installation Step	Installation Schematic Diagram
	3-1 Install the drain hose,tighten it with a screw driver. About its installation,Refer the installation of the hose.	
	3-2 Wrap the drain hose by sealing sponge.	
Drain Hose Installation	3-3 Insert the drain hose with an insulated protective tube.	
	3-4 Strap it by tie.	

	Installation Step	Installation Schematic Diagram
Block the drain	4-1 Insert the chock plug into end of the drain hose on the water basin. In order to avoid leakage, make sure to install the chock plug. After installing, its end must be close to end of the drain hose.	
hose	4-2 Wrap end of the drain hose by sealing sponge,and strap it by tie.	BG
Drainage test	5-1 Inject water to the water basin, check operation state of the drain pump. After installing the drain pump, make sure to test drainage, so as to avoid unsmooth waterway and prevent overflowing of water from the indoor unit.	



- ·The draining pump must be equipped with the products specified by the Company.
- ·In case of any claim due to unauthorized modification of the draining pump,the Company shall assume no liability.