

MODEL NUMBER:
LC-V1359


INSTRUKCJA MONTAŻU

1. LISTA CZĘŚCI


			
rama	pedały	rączka	przednie kółko
			
kółka treningowe	siodełko		

2. MONTAŻ

1. Przełóż kwadratową rurkę przedniego widelca przez dolny otwór w kuli (element z otworem na śrubę). Następnie połącz go z kierownicą, jak pokazano na rysunku.




2. Zamontuj siodełko w ramie rowerka.



3. Zamontuj kółka treningowe do otworów w tylnej osi po obu stronach jak pokazano na rysunku (Uwaga: Rozróżnij lewy i prawy by nie zamontować ich na odwrót)



4. Zamontuj pedały po obu stronach przedniej osi (jak pokazano na rysunku)



OSTRZEŻENIA:

Produkt przeznaczony dla dzieci w wieku od 2 do 4 lat, maksymalne obciążenie to 30kg.

Uważnie przeczytaj poniższe instrukcje aby uniknąć wypadków!

1. Montaż powinien być wykonywany wyłącznie przez osoby dorosłe!
2. Nigdy nie pozostawiaj dziecka bez opieki w trakcie używania rowerka.
3. Dziecko nie powinno wjeżdżać, wpadać lub najeżdżać na przedmioty i ludzi w trakcie jazdy na rowerku.
4. Używać wyłącznie na płaskich, równych, suchych powierzchniach.
5. Nie używać w okolicach ruchu drogowego, jezdni i poruszających się samochodów.
6. Należy szczególnie uważać aby żadne luźne części ubrania, włosy czy palce nie znalazły się w zasięgu kół rowerka.
7. Z rowerka może korzystać tylko jedna osoba na raz.
8. Nie używaj produktu jeżeli brakuje części lub są one w jakikolwiek sposób uszkodzone.
9. Unikać wystawiania na działanie deszczu.
10. Sprawdzaj regularnie stan produktu, działanie i mocowania śrub.
11. Produkt przed montażem zawiera małe/ostre elementy niebezpieczne dla dzieci, grożące udławieniem bądź uszkodzeniem ciała. Chronić przed zasięgiem dzieci przed ukończeniem montażu.
12. Przed użyciem usunąć wszelkie elementy pakowania.
13. Oprócz dzieci nie można kłaść na pojeździe żadnego innego ładunku, w przeciwnym razie będzie to miało wpływ na stabilność pojazdu.

Wiek dziecka: 2-4 lata

Materiały wykonania: PP i stalowe elementy

Wymiary produktu: 69 x 35 x 50 cm

Wymiary opakowania: 63,5 x 23 x 17 cm

MULTISTORE ECOTOYS Krystian Ślebioda Sady,
Logistyczna 31, 62-080 Tarnowo Podgórne

b2b-multistore.eu

MANUAL ASSEMBLY


MODEL NUMBER:
LC-V1359

1. PARTS LIST


			
frame	pedals	handle	front wheel
			
training wheels	saddle		

2. INSTALLATION

1. Insert the square tube of the front fork through the lower hole in the ball (element with screw hole). Then connect it to the handlebar as shown in the picture.




2. Install the saddle into the bike frame.



3. Install the training wheels into the holes in the rear axle on both sides as shown in the picture (Note: Differentiate between left and right to avoid installing them the other way around)



4. Install the pedals on both sides of the front axle (as shown in the picture)



WARNINGS:

The product is intended for children aged 2 to 4 years, maximum load is 30 kg. Read the instructions below carefully to avoid accidents!

1. Installation should only be performed by adults!
2. Never leave your child unattended while using the bike.
3. The child should not drive into, bump into or run over objects and people while riding a bicycle.
4. Use only on flat, even, dry surfaces.
5. Do not use near traffic, roads or moving cars.
6. Particular care should be taken to ensure that no loose clothing, hair or fingers are within the reach of the bicycle wheels.
7. Only one person can use the bike at a time.
8. Do not use the product if parts are missing or damaged in any way.
9. Avoid exposure to rain.
10. Regularly check the condition of the product, operation and screw fastening.
11. Before assembly, the product contains small/sharp elements dangerous to children, posing a choking hazard or bodily harm. Keep out of reach of children until assembly is completed.
12. Remove all packaging components before use.
13. Apart from children, do not place any other load on the vehicle, otherwise it will affect the stability of the vehicle.

Child's age: 2-4 years

Materials: PP and steel elements Product dimensions: 69 x 35 x 50 cm Packaging dimensions: 63.5 x 23 x 17 cm

MULTISTORE ECOTOYS Krystian Ślebioda Sady,
Logistyczna 31, 62-080 Tarnowo Podgórne

b2b-multistore.eu