

INSTRUKCJA OBSŁUGI

Zanim rozpoczniesz użytkowanie parasola, pamiętaj aby przeczytać poniższą instrukcję. W przypadku przekazania produktu osobie trzeciej, należy jej przekazać tę instrukcję. Instrukcja powinna być przechowywana przez cały okres użytkowania parasola.

OSTRZEŻENIE!

Folia i opakowanie nie są zabawką – trzymać z daleka od dzieci, grozi uduszeniem!

1. Rozpakowanie i Montaż:

1. Otwórz opakowanie i sprawdź, czy zestaw zawiera wszystkie elementy, tj . Parasol, ścianki boczne, wbijak, 8 śledzi, linki odprowadzające.
2. Znajdź odpowiednie miejsce na wędkarskim stanowisku, gdzie chcesz zamontować parasol.
3. Przypnij ścianki do parasola na rzepy.

2. Rozkładanie Parasola:

1. Ustaw parasol w pionie na wybranym stanowisku.
2. Sprawdź, czy wszystkie pręty są prawidłowo umieszczone w swoich otworach.
3. Upewnij się, że płótno parasola jest naciągnięte równomiernie na wszystkich prętach.

3. Regulacja Kąta Nachylenia:

1. Zlokalizuj na trzonku mechanizm regulacji i dostosuj kąt nachylenia według własnych preferencji.

4. Zabezpieczenie przed Wiatrem:

1. Za pomocą wbijaka przymocuj parasol do podłoża. Ścianki przytwierdź za pomocą śledzi i linek odprowadzających.
2. W przypadku silnego wiatru zaleca się dodatkowe zabezpieczenie, na przykład użycie specjalnych kotewek lub worków z piaskiem, które utrzymają parasol na miejscu.

5. Czyszczenie i Konserwacja:

1. Regularnie czyść parasol, usuwając z niego piasek, błoto lub inne zanieczyszczenia.
2. Jeśli parasol jest mokry, pozostaw go na zewnątrz, aby wyschnął całkowicie przed zapakowaniem go do torby lub pokrowca.
3. Sprawdzaj regularnie stany techniczne, takie jak uszkodzenia materiału czy luzujące się elementy, i naprawiaj je natychmiast, aby uniknąć większych problemów w przyszłości.

USER MANUAL

Before you start using the umbrella, remember to read the instructions below. If you pass the product on to a third party, please pass on these instructions to that person. The manual should be kept for the entire period of use of the umbrella.

WARNING!

The foil and packaging are not toys - keep away from children - risk of suffocation!

1. Unpacking and Assembly:

1. Open the package and check whether the set contains all the elements, i.e. Umbrella, side walls, nailer, 8 pegs, drainage ropes.
2. Find a suitable place on the fishing site where you want to mount the umbrella.
3. Attach the sides to the umbrella with Velcro.

2. Unfolding the Umbrella:

1. Place the umbrella vertically on the selected position.
2. Check that all rods are correctly placed in their holes.
3. Make sure the umbrella canvas is stretched evenly over all rods.

3. Tilt Angle Adjustment:

1. Locate the adjustment mechanism on the shaft and adjust the angle of inclination to your preference.

4. Wind Protection:

1. Use a nailer to attach the umbrella to the ground. Fix the walls with pegs and drainage ropes.
2. In case of strong winds, additional protection is recommended, such as using special anchors or sandbags to keep the umbrella in place.

5. Cleaning and Maintenance:

1. Clean your umbrella regularly to remove sand, mud or other debris.
2. If the umbrella is wet, leave it outside to dry completely before storing it in a bag or cover.
3. Check regularly for technical conditions, such as material damage or loose parts, and repair them immediately to avoid major problems in the future.