



User Instructions for compatible Canon 057 Series



"Cart. Comm. Error. A counterfeit or non-Canon cartridge may be in use. Close: Press OK "

Every time the machine is restarted, the printer will prompt the message shown above. Please follow the prompts and press **OK**, then you can print normally.

NOTE: The illustrations shown above are from a representative product and may differ from your machine. This does not affect the use of our product.

Za każdym razem, gdy urządzenie zostanie ponownie uruchomione, drukarka wyświetli komunikat powyżej. Postępuj zgodnie z instrukcją i naciśnij OK, aby móc normalnie drukować.