




Grace 60" Double Bathroom Vanity in Enhanced Brown Oak
Ready to Assemble



Assembly Instructions

SKU# 2-01-37-60-27112V08

CONTENTS



Parts Overview _____ 3



Dimensions _____ 4-5



Assembly Instructions _____ 6-7



Full View _____ 8



Removal _____ 9-12




Tips & Care _____ 13




Support & Contact _____ 14

BASE PARTS



(A)
Base



(B)
Backsplash


HARDWARE

DIMENSIONS

Measures in: millimeter [inch]

WARNING:

- The vanity must be securely fastened to the wall to prevent the possibility of tip-over.
- Le meuble-lavabo doit être solidement fixé au mur pour éviter tout risque de basculement.
- El tocador debe estar firmemente fijado a la pared para evitar el riesgo de vuelco.



Installation Manual

- Carefully read the instructions before starting the installation.
- This vanity should be installed by an experienced plumber
- Drain pipe and drain trap are not supplied. Connect to existing drain pipe.


Manuel d'installation

- Lire attentivement les instructions avant de commencer l'installation.
- Cette vanité doit être installée par un plombier expérimenté.
- Le tuyau de vidange et le siphon ne sont pas fournis. Connectez-les au tuyau de vidange existant.


Manual de instalación

- Lea atentamente las instrucciones antes de comenzar la instalación.
- Este tocador debe ser instalado por un plomero experimentado.
- El tubo de desagüe y el sifón no están incluidos. Conéctelos a una tubería de desagüe existente.

DIMENSIONS





STEP ONE



(A)
Base



(D)
Level
(Not Included)




INSTRUCTIONS:

- Place the assembled base (I) in the final position.
- Use a Level (not included) to check that the cabinet is even and balanced.
- Adjust the height of the legs as needed:
 - Turn the leveler counter clockwise if it is low.
 - Turn the leveler clockwise to lower


Confirm the above is accurate for assembly.

- Make sure the cabinet is level and that all corners are straight and square before connecting plumbing or installing tile or a backsplash.


STEP TWO






(A)
Base



(B)
Backsplash




(E)
Caulk Gun & Silicone
(Not Included)




INSTRUCTIONS:

- Apply a bead of Silicone to the back of the backsplash (B) using a caulk gun.
- Carefully place the backsplash (B) onto the top rear edge of the base (A).
- Press the backsplash (B) firmly against the wall and the rear of the top (A).
- Check Alignment: Ensure there is no gap (or 0mm) between the top edge of the backsplash (B) and the wall.

FINAL ASSEMBLY VIEW





Front



Back


TAKE OUT DRAWERS



TAKE OUT DRAWERS:

- a. Remove the drawer by pressing on the plastic buckles below the bottom two sides of the drawer with both index fingers as shown in picture 1, then the plastic buckles open as shown in picture 2 and pull out the drawer, similar in removing the remaining drawer.



REMOVAL STONE TOP



(A)
Base




(1)
Allen Key




REMOVAL STONE TOP:

- a. Unscrew 6 bolts underside of stone top.
- b. Lift the stone top and move off the wooden case.



INSERT STONE TOP







(A)

Base



(1)

Allen Key



INSERT STONE TOP:

a. Insert stone top.






b. Helpful Hint:

Set top on its edge at back of counter.

Using overhang of sink to lower the front of the marble top to the cabinet base, making sure both ends come down at the same rate. Do not shimmy, twist or turn the top as you lower it,

- risk of breakage.

PUT THE DRAWERS IN CABINET



PUT THE DRAWERS IN CABINET:

- a. Insert the drawer by aligning the position of the slide locating pin and the hole behind the drawer as shown, then push the drawer in. Put first drawer (see picture) and remaining drawers put the same.
- b. Roll the clip to adjust drawer height

TIPS & CARE

General Tips:

Assemble on a flat surface, periodically check and tighten fasteners as necessary, indoor residential use only, do not over tighten fasterns.

CARRARA QUARTZ

✓	✗
Wipe up spills promptly	Don't use bleach, ammonia, or harsh chemicals
Use a soft cloth or non-abrasive sponge	Don't use abrasive scrubbers or scouring pads
Clean with mild dish soap and warm water	Don't place hot tools (e.g., curling irons, straighteners) directly on the surface

WOOD

✓	✗
Dust Regularly	Don't use abrasive sponges, steel wool, or harsh chemicals
Use mild soap and water for cleaning when needed, always wipe dry immediately	Don't leave standing water, soap, or cleaners on surfaces
Place the furniture in a climate-stable space	Don't use multi-surface sprays or anything containing ammonia or bleach

HARDWARE

✓	✗
Use mild soap and warm water to clean — dry immediately with a soft towel	Don't use abrasive pads, wire brushes, or scouring powders — they can scratch the finish
Tighten loose screws or fittings gently if movement is noticed	Don't hang heavy bags or items from handles or knobs — this can loosen or bend fittings
Check alignment and tension periodically on hinges and glides	Don't allow water or cleaning solution to sit around screw holes or hardware bases

SUPPORT

Need Assistance?

If you have any questions about assembly, product functionality, or care, we're here to help. Our team is available to provide support throughout the process and beyond. Whether you need replacement parts, clarification on instructions, or guidance for product maintenance, please don't hesitate to reach out.

We aim to respond to all inquiries within one to two business days.

Warranty

This product is covered under a 1-year limited warranty from the date of purchase. The warranty covers defects in materials and workmanship under normal residential use. This warranty does not cover damage caused by improper assembly, modification, accidents, misuse, or normal wear and tear. Natural variations in materials and finishes are not considered defects.

For warranty service or questions, please contact our support team with your order number and a description of the issue.

We're here to help!

CONTACT

Customer Support

Highbury Furnishings

Email: Support@highburyfurnishings.com

Phone: 1-617-286-6350

Hours: Monday–Friday, 9 AM – 5 PM (EST)

Website: www.HighburyFurnishings.com