



MTK[®]

SPARE PARTS OF EARTHMOVING MACHINES



www.mtkmakina.com

In 2002, MTK Makina was established as a domestic manufacturer of earthmoving machineries' spare parts aiming at satisfying the market needs inside of Turkey. By the beginning of the third millennium, MTK Makina has witnessed a turning point in the growth of its factors of production and technical processes which have allowed us to expand and compete within the international market with our scope focus on our first rate quality standards. MTK Makina produces Komatsu Dozer and Grader, Mitsubishi Grader spare parts and exports the goods to more than 50 countries.


MTK Makina manufactures its products with various kinds of tool and loom such as Vertical Machining Center, CNC Lathe, Drilling Machine, Universal Turning Machine, Profile Grinding Machine, Gear Hobbing Machine, Welding Machine and Milling Machine.

Our activities in the field of construction equipment spare parts have been continuing since 2002 and our company has adopted customer satisfaction and honesty as a principle and it is a constantly growing and developing company in line with this principle.

Our quality standards with ISO 9001:2015 certified are applied from enquiry stage to delivery and post-delivery stage.

We envision MTK Makina as the leader in providing the high quality replacement parts globally. We don't believe that individual growth exists, we believe that growing can be realized with the same level of growth all our stakeholder.

Our mission is providing our market with premium quality replacement parts aligned with the international standards that can meet our customers' expectations and maintain their long term satisfactions while using eco-friendly factors of production.



1	01084-02055	BOLT	39	04064-07525	RING SNAP
2	01084-02070	BOLT	40	04064-08530	RING
3	01530-03610	NUT	41	04064-09030	RING
4	01580-12419	NUT	42	04065-01140	RING-SNAOP
5	01582-11210	NUT	43	04065-01240	RING-SNAOP
6	01582-11411	NUT	44	04065-05520	RING
7	01582-12016	NUT	45	04065-06220	RING
8	01583-13923	NUT	46	04065-09530	RING
9	01590-14548	NUT	47	04066-00060	RING
10	01593-11210	NUT	48	04066-00075	RING
11	01593-11613	NUT	49	04070-00110	RING
12	01593-13018	NUT	50	04080-06012	HOLDER
13	01593-13621	NUT	51	04081-06012	LOCK
14	01593-32414	NUT	52	04205-10616	PIN
15	01602-20825	WASHER	53	04205-10822	PIN
16	01602-21030	WASHER	54	04250-10822	PIM
17	01602-21236	WASHER	55	04250-14474	ROD END
18	01641-20508	WASHERS	56	04250-41265	ROD END
19	01643-31232	WASHER	57	04250-61265	ROD END
20	01643-31445	WASHER	58	04252-01061	END
21	01643-32460	WASHER	59	04252-01269	ROD END
22	01643-33080	WASHER	60	04252-11061	END
23	01643-61645	WASHER	61	04252-11269	ROD END
24	01658-23618	WASHER	62	04260-00635	BALL
25	01803-02228	NUT	63	04412-00613	RIVET
26	04020-01228	PIN	64	06000-06009	BEARING
27	04020-01434	PIM	65	06000-06011	BEARING
28	04020-01638	PIM	66	06000-06015	BEARING
29	04050-12018	PIM	67	06000-06918	BEARING
30	04050-13020	PIM	68	06000-06921	BEARING
31	04050-13028	PIM	69	06030-23134	BEARING
32	04050-14025	PIM	70	06040-06209	BEARING
33	04050-16045	PIN	71	06040-06211	BEARING
34	04050-41056	ROD	72	06044-00207	BEARING
35	04050-61056	ROD END	73	06044-00209	BEARING
36	04050-91056	ROD END	74	06044-00212	BEARING
37	04052-91056	ROD END	75	07001-02055	RING
38	04064-04518	RING	76	07002-11823	RING

KOMATSU PART LIST



77	07005-01612	GASKET	115	07144-10506	BUSHING
78	07012-00062	SEAL	116	07144-10808	BUSH
79	07012-10145	SEAL	117	07144-11110	BUSHING
80	07012-20042	SEAL	118	07145-00045	SEAL
81	07013-10120	SEAL	119	07145-00050	SEAL
82	07018-00954	SEGMAN	120	07145-00055	DUST
83	07018-01805	RING	121	07052-31624	PLUG
84	07018-10703	RING	122	07155-00515	WEAR RING
85	07018-11805	RING SEAL	123	07155-00615	WEAR RING
86	07018-20352	SEAL RING	124	07155-00620	WEAR RING
87	07018-20353	SEAL RING	125	07155-00720	WEAR RING
88	07018-21115	SEGMAN	126	07155-00820	WEAR RING
89	07018-21155	SEGMAN	127	07155-00925	WEAR RING
90	07018-21205	RING	128	07155-01025	WEAR RING
91	07018-31104	RING	129	07155-01125	WEAR RING
92	07020-00000	FITTING	130	07155-01230	WEAR RING
93	07020-00675	FITTING	131	07155-01330	WEAR RING
94	07020-00900	FITTING	132	07155-01435	WEAR RING
95	07138-00980	CAP	133	07155-01535	WEAR RING
96	07030-00252	BREATHER	134	07155-01640	WEAR RING
97	07040-11812	PLUG	135	07155-01845	WEAR RING
98	07040-13016	PLUG	136	07155-02045	WEAR RING
99	07043-00108	PLUG	137	07155-02250	WEAR RING
100	07043-00211	PLUG	138	07155-02555	WEAR RING
101	07046-16529	PLUG	139	07156-00710	WEAR RING
102	07051-00000	CAP A	140	07156-00810	WEAR RING
103	07051-20000	CAP A	141	07156-00912	WEAR RING
104	07053-10000	CAP A	142	07156-01012	WEAR RING
105	07056-18416	STRANIER	143	07156-01520	WEAR RING
106	07069-25400	STRAINER	144	07156-01620	WEAR RING
107	07137-05008	BUSHING	145	07156-01822	WEAR RING
108	07137-05509	BEARING	146	07156-02022	WEAR RING
109	07139-00902	SHIM T=0,2 MM	147	07161-10050	PİSTON RING
110	07139-00905	SHIM T=0,5MM	148	07161-10060	PİSTON RING
111	07143-10505	BUSHING	149	07161-10070	PİSTON RING
112	07143-10506	BUSHING	150	07161-10080	PİSTON RING
113	07144-10404	BUSHING	151	07161-10090	PİSTON RING
114	07144-10405	BUSHING	152	07161-10140	PİSTON RING

153	07165-03336	NUT	191	09233-03820	THRUST WASHER
154	07165-12022	NUT	192	09233-05125	WASHER
155	07165-12426	NUT	193	09233-15125	WASHER
156	07165-12729	NUT	194	09233-12020	WASHER
157	07165-13033	NUT	195	09233-12620	WASHER
158	07165-13336	NUT	196	09233-12920	WASHER
159	07165-14547	NUT LIFT ROD	197	09233-13220	WASHER
160	07165-15252	NUT	198	09255-06245	PIN
161	07165-16264	NUT	199	09370-00070	PACKING
162	07177-03025	BUSHING	200	09370-00090	PACKING
163	07177-09035	BUSHING	201	103-15-12811	SEAL RING
164	07179-00049	RING	202	103-15-12820	SEAL RING
165	07211-00610	NIPPLE	203	103-15-12861	SEAL RING
166	07211-50610	NIPPLE	204	113-15-12861	SEAL RING
167	07218-50610	NIPPLE	205	113-15-12870	SEAL RING
168	07235-10422	ELBOW	206	113-15-21320	PLUG
169	07235-50315	ELBOW	207	113-15-22711	PLATE
170	07235-50422	ELBOW	208	113-15-29250	SEAL RING
171	07281-00489	CLAMP	209	114-63-55170	BUSHING
172	07332-02400	COUPLING	210	11Y-06-11372	LAMP
173	07332-52400	GASKET	211	11Y-06-11391	SWICH
174	07332-62400	CLAMP	212	124-15-41380	SLEEVE
175	07959-20001	VALVE	213	124-15-41910	SEAL RING
176	08061-50010	SWICH	214	124-15-41920	SEAL RING
177	08086-01000	SWICH	215	124-15-42720	PLATE
178	08086-10000	SWICH	216	124-15-49410	BEARING
179	08088-20000	SWICH	217	124-32-53140	BUSHING
180	08128-22400	LAMP	218	124-911-1430	HOOD
181	08128-32400	LAMP	219	125-15-11230	PLUG
182	08601-03000	AMMETER	220	125-15-32380	PLATE
183	08620-00000	SENSOR	221	125-15-32750	PLATE
184	08641-05000	AMMETER	222	125-15-39210	SEAL RING
185	08643-01000	GAUGE	223	125-15-39220	SEAL RING
186	08643-02000	GAUGE	224	130-30-13129	SHAFT
187	08643-31000	GAUGE	225	131-30-00110	BUSHING
188	09232-03238	BRARNG	226	131-30-34140	PISTON
189	09233-02620	WASHER	227	131-30-44140	PISTON
190	09233-02920	WASHER	228	131-30-46120	BUSHING

KOMATSU PART LIST



229	131-30-46130	BUSHING	267	135-30-34150	CYLINDER
230	13F-50-31130	BUSHING	268	135-43-34180	CABLE
231	13F-50-31131	BUSHING	269	140-70-00032	PIVOT ASSY
232	134-12-61112	COVER	270	140-70-13141	PIVOT
233	134-12-61121	SHAFT	271	140-70-13151	CAP
234	134-12-61131	DAMPER	272	140-817-3150	TRUNNION
235	134-12-71160	SHAFT	273	141-30-33122	SHAFT
236	134-15-12840	SEAL RING	274	141-30-33134	BRACKET ASSY LH
237	134-15-12850	SEAL RING	275	141-30-33144	BRACKET ASSY RH
238	134-15-12860	SEAL RING	276	141-30-34210	CYLINDER
239	134-15-12870	SEAL RING	277	143-13-05050	TORK KITI
240	134-27-61531	PINION	278	143-15-05130	ŞANZ.VALF KIT
241	134-27-61232	GEAR	279	144-13-05010	TORK KITI
242	134-27-61240	PINNION	280	144-13-11140	GEAR
243	134-27-61251	GEAR	281	144-13-11650	SHAFT
244	134-27-61261	SHAFT	282	144-13-11661	COUPLING
245	134-27-61320	SPACER	283	144-13-12523	SHAFT
246	134-27-61560	HUB	284	144-13-12524	SHAFT
247	134-50-61111	PIVOT SHAFT	285	144-15-05010	ŞANZ KITI
248	134-50-62111	EQULAZIER BAR	286	144-15-05100	KIT
249	134-50-62112	EQULAZIER BAR	287	144-15-22571	WASHER
250	134-50-62150	BEARING	288	144-15-22871	SEAL RING
251	134-50-61171	RING	289	144-15-22881	SEAL RING
252	134-63-12220	ROD	290	144-15-29110	SEAL RING
253	134-63-12020	ROD	291	144-60-15384	CYLINDER
254	135-03-31230	RADIATOR	292	144-60-15374	CYLINDER
255	135-12-31100	DAMPER	293	144-60-15431	BUSHING
256	135-12-31102	DAMPER	294	144-60-15450	BUSHING
257	135-12-31130	FLANGE	295	144-63-05050	KIT
258	135-12-31330	SHAFT	296	144-63-12100	CYLINDER ASSY
259	135-13-31361	COUPLING	297	144-63-12200	CYLINDER SSSY
260	135-13-31362	COUPLING	298	144-63-12720	ROD
261	135-27-31210	PINION	299	144-63-13100	HYDRAULIC CYLINDER ASSY L.H
262	135-27-31310	GEAR	300	144-63-13200	HYDRAULIC CYLINDER ASSY R.H
263	135-27-31410	PINION-11 TEET	301	144-63-12120	PISTON
264	135-27-31510	GEAR	302	144-63-12130	HEAD
265	135-30-33120	BRACKET	303	144-63-12131	HEAD
266	135-30-33130	BRACKET	304	144-63-12360	NUT

305	144-63-42182	NUT	343	14X-11-11310	SHAFT
306	144-70-13160	TRUNNION	344	14X-12-11102	DAMPER
307	144-70-13180	TRUNNION	345	14X-12-11210	COVER
308	144-70-13181	TRUNNION	346	14X-12-11311	YOKE
309	144-70-13190	SHAFT-WELDED	347	14X-15-12310	CARRIER
310	144-817-1260	PIN	348	14X-15-12661	GEAR
311	144-817-2420	CAP	349	14X-15-22121	SHAFT
312	144-920-3211	TRUNNION	350	14X-15-22240	GEAR
313	145-03-41250	RADIATOR	351	14X-15-22250	GEAR
314	145-14-31620	MAGNET	352	14X-15-22310	CARRIER
315	145-63-23100	CYLINDER ASSY	353	14X-15-22330	CARRIER
316	145-63-23120	ROD	354	14X-15-22340	CARRIER
317	145-63-23130	HEAD	355	14X-15-22350	CARRIER
318	145-63-23140	CYLINDER LH	356	14X-15-22351	CARRIER
319	145-63-23200	CYLINDER ASSY	357	14X-15-22430	GEAR
320	145-63-23300	CYLINDER ASSY	358	14X-15-22440	GEAR
321	145-63-23400	CYLINDER ASSY	359	14X-15-22510	PIN
322	145-63-23240	CYLINDER RH	360	14X-15-22520	PIN
323	145-63-32600	CYLINDER ASSY	361	14X-15-22530	PIN
324	145-63-32601	CYLINDER ASSY	362	14X-15-22540	PIN
325	145-63-32621	PISTON	363	14X-15-22610	GEAR
326	145-63-32630	HEAD	364	14X-15-22640	GEAR
327	145-63-32640	CYLINDER	365	14X-15-22661	GEAR
328	145-63-32666	BUSHING	366	14X-15-22670	GEAR
329	145-63-32700	CYLINDER	367	14X-15-22730	PISTON
330	145-63-32701	CYLINDER	368	14X-15-22740	PISTON
331	145-63-32740	CYLINDER	369	14X-15-22750	PISTON
332	14U-70-12120	JOINT	370	14X-15-22760	PISTON
333	14U-70-12520	JOINT	371	14X-15-22770	PISTON
334	14X-03-11212	RADIATOR	372	14X-15-21160	HOUSING
335	14X-03-11312	RADIATOR	373	14X-15-31160	HOUSING
336	14X-03-11314	RADIATOR	374	14X-27-11243	COVER
337	14X-10-11712	STRAINER	375	14X-27-11212	PINION
338	14X-11-11120	SHAFT	376	14X-27-11220	CAGE
339	14X-11-11100	SHAFT ASS	377	14X-27-11312	GEAR
340	14X-11-11200	SHAFT ASS	378	14X-27-11412	PINION
341	14X-11-11220	SHAFT	379	14X-27-11431	COVER
342	14X-11-11221	SHAFT	380	14X-27-11502	CARRIER ASS

KOMATSU PART LIST



381	14X-27-11512	CARRIER	419	14X-71-12230	BUSHING
382	14X-27-11522	GEAR	420	14X-71-12240	BUSHING
383	14X-27-11542	SHAFT	421	14X-71-13111	BRACE
384	14X-27-11552	PLATE	422	14X-911-3210	WIPER
385	14X-27-11560	LOCK	423	14X-911-3310	WIPER
386	14X-27-11612	GEAR	424	14X-911-3321	WIPER
387	14X-27-11621	HUB	425	14X-911-3330	WIPER
388	14X-27-11622	HUB	426	14X-911-7112	COMPRESSOR
389	14X-27-11633	HOLDER	427	14X-911-7501	BLOWER
390	14X-27-11710	HUB	428	14X-916-1341	SHAFT
391	14X-27-11711	HUB	429	14X-Z11-8580	COMPRESSOR
392	14X-27-11751	COLLAR	430	14Y-30-00210	PIVOT SHAFT
393	14X-27-31210	PINION	431	14Y-30-16133	GUARD
394	14X-27-31710	HUB	432	14Y-30-17111	PIVOT SHAFT
395	14X-30-00210	PIVOT SHAFT ASSY	433	14Y-30-18130	BUSHING
396	14X-30-13114	CYLINDER	434	14Y-30-18140	BUSHING
397	14X-30-13115	CYLINDER	435	14Y-30-18150	SEAL
398	14X-30-13124	YOKE	436	14Y-30-18160	SPACER
399	14X-30-13142	SHAFT	437	14Y-50-00012	EQUALIZER-BAR ASSY
400	14x-30-13143	SHAFT	438	14Y-50-11110	EQUALIZER-BAR ASSY
401	14X-30-13510	CYLINDER	439	14Y-50-11240	PIN
402	14X-30-13512	CYLINDER	440	14Y-50-11250	BUSHING
403	14X-30-17111	PIVOT SHAFT	441	14Y-50-11314	PIN
404	14X-30-26140	GUARD	442	14Y-50-11421	BUSHING
405	14X-50-00012	BAR ASS	443	14Y-50-11450	BUSH
406	14X-50-11110	BAR	444	14Y-50-11460	BUSHING
407	14X-63-01062	CYLINDER ASSY	445	14Y-63-01013	CYLINDER ASSY
408	14X-63-01063	CYLINDER ASSY	446	14Y-63-01014	CYLINDER ASSY
409	14X-63-12221	ROD PISTON	447	14Y-63-01016	CYLINDER ASSY
410	14X-63-12242	CYLINDER	448	14Y-63-01017	CYLINDER ASSY
411	14X-63-12243	CYLINDER	449	14Y-63-01032	TILT CYLINDER ASSY
412	14X-63-X1062	CYLINDER ASSY	450	14Y-63-01033	TILT CYLINDER ASSY
413	14X-63-X1063	CYLINDER ASSY	451	14Y-63-12121	ROD
414	14X-63-X1072	CYLINDER ASSY	452	14Y-63-12131	PISTON SUB ASSY
415	14X-63-X1073	CYLINDER ASSY	453	14Y-71-11141	BRACKET
416	14X-70-00070	PILOT ASSY	454	14Y-71-11190	BRACKET
417	14X-70-00071	PILOT ASSY	455	14Y-71-11220	BRACKET
418	14X-70-00072	PILOT ASSY	456	14Y-71-11230	BRACKET

457	14Y-71-12131	JOINT	495	150-30-15553	SPACER
458	14Y-71-12170	BRACKET	496	150-30-15563	BOLT
459	14Y-71-13120	STUD	497	150-70-00240	BRACKET
460	14Y-71-13160	JOINT	498	150-70-13411	PIN
461	14Y-63-14143	CYLINDER	499	150-70-23153	BRACKET
462	14Y-63-12144	CYLINDER	500	150-70-23244	CAP
463	14Y-63-X1014	CYLINDER ASSY	501	150-70-23314	SHAFT
464	14Y-63-X1016	CYLINDER ASSY	502	150-70-23315	SHAFT
465	14Y-63-X1017	CYLINDER ASSY	503	154-01-21310	CUSHION
466	14Y-63-X1024	CYLINDER ASSY	504	154-03-21131	RADIATOR
467	14Y-63-X1026	CYLINDER ASSY	505	154-03-75911	RADIATOR
468	14Y-63-X1027	CYLINDER ASSY	506	154-03-75913	FLANGE
469	14Y-63-52121	ROD,PISTON	507	154-12-71220	SHAFT
470	14Y-63-52142	CYL	508	154-13-41651	SHAFT
471	14Y-63-52143	CYL	509	154-13-41660	YOKE
472	14Y-71-12150	CAP(ONLY CAP)	510	154-13-41661	YOKE
473	14Y-71-22150	CAP(ONLY CAP)	511	154-13-42120	RACE
474	14Y-71-22151	CAP(ONLY CAP)	512	154-13-42521	SHAFT
475	14Y-71-00070	PILOT ASSY	513	154-15-00240	PLATE
476	14Y-71-00072	PILOT ASSY	514	154-15-00271	PLATE
477	14Y-71-00080	PILOT ASSY L.H	515	154-15-12550	WASHER
478	14Y-71-00081	PILOT ASSY L.H	516	154-15-13213	GEAR
479	14Y-71-00082	PILOT ASSY L.H	517	154-15-13234	GEAR
480	14Y-71-00090	PILOT ASSY R.H	518	154-15-22742	PISTON
481	14Y-71-00091	PILOT ASSY R.H	519	154-15-32110	SHAFT
482	14Y-71-00092	PILOT ASSY R.H	520	154-15-32120	GEAR
483	14Y-71-00150	BRACE ASSY	521	154-15-32150	COUPLING
484	14Y-71-00151	BRACE ASSY	522	154-15-33211	GEAR
485	14Y-71-00160	BRACE ASSY	523	154-15-33230	GEAR
486	14Y-71-00161	BRACE ASSY	524	154-22-22280	PIN
487	14Y-71-13110	BRACE	525	154-27-11152	FLANGE
488	14Y-71-13120	SHAFT(WELDED)	526	154-27-11250	GEAR
489	14Y-71-13170	BRACKET R.H	527	154-27-11256	GEAR
490	14Y-71-13211	TRUNNION	528	154-27-11310	GEAR
491	14Y-71-13530	BRACKET L.H	529	154-27-11313	GEAR
492	14Z-71-33211	TRUNNION	530	154-27-11320	PINION
493	14Z-71-33212	TRUNNION	531	154-27-11326	PINION
494	14Z-50-31530	PIN	532	154-27-11327	PINION

KOMATSU PART LIST



533	154-27-11330	KEY	571	154-30-11810	BUSHING
534	154-27-12131	FLANGE	572	154-30-11840	SHAFT
535	154-27-12151	FLANGE	573	154-30-11880	SHAFT
536	154-27-12152	FLANGE	574	154-30-12611	SUPPORT
537	154-27-12161	FLANGE	575	154-30-12621	SUPPORT
538	154-27-12162	FLANGE	576	154-30-12630	GUIDE-ASSY
539	154-27-12313	SHAFT	577	154-30-12631	GUIDE-ASSY
540	154-27-12320	BOLT	578	154-30-12640	GUIDE-ASSY
541	154-27-12352	COLLAR	579	154-30-23122	SHAFT
542	154-27-12412	NUT	580	154-30-71310	GUARD L.H
543	154-27-15110	GUARD	581	154-30-71320	GUARD RH
544	154-27-15120	GUARD	582	154-30-71331	GUARD
545	154-27-71611	GUARD L.H	583	154-30-71341	GUARD
546	154-27-71621	GUARD R.H	584	154-30-72652	GUIDE ASSY
547	154-27-72191	CARRIER	585	154-30-72720	GUIDE PLATE
548	154-27-72241	GEAR	586	154-30-72731	SUPPORT LH
549	154-27-72250	GEAR	587	154-30-72741	SUPPORT RH
550	154-27-72310	PIN	588	154-30-73150	CYLINDER
551	154-27-72320	SPACER	589	154-50-73151	CYLINDER
552	154-27-72430	SHAFT	590	154-30-73160	NUT
553	154-30-11134	PISTON	591	154-30-73170	SPACER
554	154-30-11141	CYLINDER	592	154-30-74120	SHAFT
555	154-30-11142	CYLINDER	593	154-30-74130	BUSHING
556	154-30-11145	CYLINDER	594	154-43-14432	CABLE
557	154-30-11223	SHAFT	595	154-43-43160	CABLE
558	154-30-11224	SHAFT	596	154-50-00015	EQUALIZER-BAR ASSY
559	154-30-11418	GUARD	597	154-50-00711	EQUALIZER-BAR ASSY
560	154-30-11419	GUARD	598	154-50-11115	BAR
561	154-30-11428	GUARD	599	154-50-11123	SEAT
562	154-30-11429	GUARD	600	154-50-11134	PIN
563	154-30-11437	GUARD	601	154-50-11135	PIN
564	154-30-11438	GUARD	602	154-50-11152	SUPPORT
565	154-30-11439	GUARD	603	154-50-11164	BUSHING
566	154-30-11447	GUARD	604	154-50-11170	BUSHING
567	154-30-11448	GUARD	605	154-50-11171	BUSHING
568	154-30-11612	CAP	606	154-50-72110	EQUALIZER-BAR
569	154-30-11682	GUARD	607	154-50-71120	FLANGE
570	154-30-11771	PISTON	608	154-50-71130	SPACER

609	154-50-71140	SPACER	647	154-63-52270	PISTON
610	154-50-71180	FLANGE	648	154-63-52402	BLADE TILT CYLINDER ASSY
611	154-50-71190	RING	649	154-63-52760	BUSHING
612	154-50-71220	FLANGE	650	154-70-00085	BRACE ASSY
613	154-50-71230	SPACER	651	154-70-12116	BRACE
614	154-50-72120	PIN	652	154-70-12162	SHAFT
615	154-50-72130	BEARING	653	154-70-17160	BRACE
616	154-50-72141	PIN	654	154-70-13214	TRUNNION
617	154-63-12230	HEAD	655	154-70-32230	BALL-WELDED
618	154-63-12340	BUSHING	656	154-71-00130	BRACKET ASSY
619	154-63-12530	PISTON,ROD	657	154-71-21290	PIN
620	154-63-12540	CYLINDER	658	154-71-22161	BRACKET
621	154-63-12541	CYLINDER	659	154-71-22162	BRACKET
622	154-63-12602	CYLINDER ASS	660	154-71-22261	JOINT
623	154-63-12603	CYLINDER ASSY	661	154-71-22470	PIN
624	154-63-12604	CYLINDER ASSY	662	154-71-71120	BRACKET
625	154-63-12702	CYLINDER ASSY	663	154-71-71320	BRACKET
626	154-63-12703	CYLINDER ASSY	664	154-71-71340	BRACKET R.H
627	154-63-12704	CYLINDER ASSY	665	154-71-71731	BRACKET L.H
628	154-63-12971	PISTON	666	154-71-71911	TRUNNION
629	154-63-19120	PISTON	667	154-71-72410	ARM
630	154-63-42130	HEAD	668	155-15-12620	GEAR
631	154-63-42170	GLAND	669	155-15-12632	GEAR
632	154-63-42320	BUSHING	670	155-15-12650	GEAR
633	154-63-42420	BUSHING	671	155-15-12880	PISTON
634	154-63-42451	PISTON	672	155-15-12892	PISTON
635	154-63-42502	RIPER CYLINDER ASSY	673	155-30-13230	SPRING
636	154-63-42503	RIPER CYLINDER ASSY	674	155-63-22180	BUSHING
637	154-63-42602	RIPER CYLINDER ASSY	675	15A-63-52120	PISTON
638	154-63-42603	RIPER CYLINDER ASSY	676	170-21-12141	NUT
639	154-63-42730	ROD.PISTON	677	170-27-11232	WASHER
640	154-63-42740	CYLINDER	678	170-27-12472	NUT
641	154-63-42741	CYLINDER	679	170-30-14211	PISTON
642	154-63-42840	CYLINDER	680	170-30-14221	BUSHING
643	154-63-42841	CYLINDER	681	170-50-12110	PAD
644	154-63-52125	ROD.PISTON	682	170-70-12240	PIN
645	154-63-52132	HEAD CYLINDER	683	170-70-13141	NUT
646	154-63-52145	CYLINDER	684	175-03-31512	HOSE

KOMATSU PART LIST



685	175-03-31513	HOSE	723	175-15-41310	COLLAR
686	175-03-32260	RADIATOR	724	175-15-42111	SHAFT
687	175-03-41530	PULLEY	725	175-15-42112	SHAFT
688	175-13-00011	CASE ASSY	726	175-15-42122	GEAR
689	175-13-21141	GEAR	727	175-15-42131	GEAR
690	175-13-21213	CASE	728	175-15-42151	COUPLING
691	175-13-21220	GEAR	729	175-15-42190	SHAFT
692	175-13-21253	PILOT	730	175-15-42212	SHAFT
693	175-13-21641	FLANGE	731	175-15-42213	SHAFT
694	175-13-21654	SHAFT	732	175-15-42311	CAGE BEARING
695	175-13-21662	COUPLING	733	175-15-42321	CARRIER
696	175-13-21770	SPACER	734	175-15-42322	CARRIER
697	175-13-22122	RACE	735	175-15-42362	CARRIER
698	175-13-22524	SHAFT	736	175-15-42363	CARRIER
699	175-13-24111	GEAR	737	175-15-42364	CARRIER
700	175-15-00240	PISTON	738	175-15-42371	GEAR
701	175-15-00250	HOUSING ASSY	739	175-15-42411	HOUSING
702	175-15-00260	HOUSING ASSY	740	175-15-42412	HOUSING
703	175-15-00261	HOUSING ASSY HIGH SERIAL	741	175-15-42420	DRUM
704	175-15-00270	PLATE	742	175-15-42421	DRUM
705	175-15-00281	HOUSING	743	175-15-42451	GEAR
706	175-15-00282	HOUSING HIGH SERIAL	744	175-15-42471	GEAR
707	175-15-00290	CAGE	745	175-15-42491	GEAR
708	175-15-00291	CAGE	746	175-15-42511	SHAFT
709	175-15-00311	SHAFT ASSY	747	175-15-42512	SHAFT
710	175-15-00312	SHAFT ASSY	748	175-15-42531	SHAFT
711	175-15-00331	HOUSING	749	175-15-42532	PIN
712	175-15-00332	HOUSING	750	175-15-42551	SHAFT
713	175-15-12730	PISTON	751	175-15-42552	PIM
714	175-15-41140	PLATE	752	175-15-42610	GEAR
715	175-15-41150	HOUSING	753	175-15-42620	GEAR
716	175-15-41160	HOUSING	754	175-15-42630	GEAR
717	175-15-41161	HOUSING	755	175-15-42631	GEAR
718	175-15-41171	PLATE	756	175-15-42650	GEAR
719	175-15-41172	PLATE	757	175-15-42740	PISTON
720	175-15-41189	HOUSING	758	175-15-42741	PISTON
721	175-15-41210	CAGE	759	175-15-42769	PISTON
722	175-15-41211	CAGE	760	175-15-42860	PISTON

761	175-15-42870	PISTON	799	175-27-32641	GUARD
762	175-15-42871	PISTON	800	175-30-23121	SHAFT
763	175-15-43151	CAGE	801	175-30-23172	BOLT
764	175-15-43152	COVER	802	175-30-23180	NUT
765	175-15-43210	GEAR	803	175-30-24131	PLATE
766	175-15-43212	GEAR	804	175-30-24222	CYLINDER
767	175-15-43232	GEAR	805	175-30-24223	CYLINDER
768	175-15-43352	CAGE	806	175-30-27133	COVER
769	175-20-11130	PLATE	807	175-30-27143	COVER
770	175-21-32112	SHAFT	808	175-30-31530	CAP L.H.
771	175-21-32113	SHAFT	809	175-30-31540	CAP
772	175-21-32162	CAGE	810	175-30-32150	SPACER
773	175-21-32190	CAGE	811	175-30-32151	SPACER
774	175-21-32153	GAUGE	812	175-30-32160	BOLT
775	175-22-21280	DRUM	813	175-30-32162	BOLT
776	175-22-21281	DRUM	814	175-30-32175	GUARD INNER L.H
777	175-27-00080	SPROCKET SUPPORT ASSY	815	175-30-32185	GUARD
778	175-27-00082	SUPPORT	816	175-30-32195	GUARD
779	175-27-22130	SPACER	817	175-30-33272	GUIDE
780	175-27-22131	SPACER	818	175-30-33282	GUIDE
781	175-27-22140	RETAINER	819	175-30-34210	SHAFT
782	175-27-22150	NUT LIFT ROD	820	175-30-37102	COVER
783	175-27-22272	NUT	821	175-30-37103	COVER
784	175-27-31161	CAGE	822	175-30-37113	SUPPORT
785	175-27-31233	PINION	823	175-30-37153	COVER
786	175-27-31255	GEAR	824	175-30-37154	COVER
787	175-27-31341	SHAFT	825	175-30-37170	COVER
788	175-27-31343	SHAFT	826	175-30-37184	COVER
789	175-27-31384	HUB	827	175-30-37186	COVER
790	175-27-31394	BOSS SPR	828	175-30-37220	COVER
791	175-27-31411	BUSHING	829	175-30-37230	COVER
792	175-27-31441	BUSHING	830	175-30-43121	GUARD
793	175-27-31463	HUB	831	175-30-43131	GUARD
794	175-27-31495	PINION	832	175-43-24670	CABLE
795	175-27-31510	SUPPORT	833	175-43-42441	ROD ASSY
796	175-27-32610	GUARD	834	175-43-42690	ROD ASSY
797	175-27-32611	GUARD	835	175-43-51320	CABLE
798	175-27-32640	GUARD	836	175-49-11222	SCREEN

KOMATSU PART LIST



837	175-49-11231	MAGNET ASSM.	875	175-63-42345	CYLINDER
838	175-50-00024	EQUALIZER BAR ASSY	876	175-63-42701	CYLINDER ASSY
839	175-50-00025	EQUALIZER BAR ASSY	877	175-63-42801	CYLINDER ASSY
840	175-50-21133	PIN	878	175-63-43121	ROD
841	175-50-21120	BUSHING	879	175-63-43142	CYLINDER
842	175-50-21134	PIN	880	175-63-43242	CYLINDER
843	175-50-22131	SEAT	881	175-63-43700	CYLINDER ASSY
844	175-50-31113	BAR	882	175-63-43800	CYLINDER ASSY
845	175-50-31114	BAR	883	175-63-44320	ROD,PISTON
846	175-50-31160	BUSHING	884	175-63-44321	ROD,PISTON
847	175-50-32111	SUPPORT	885	175-63-45320	ROD
848	175-60-19120	CAP	886	175-63-45321	ROD
849	175-60-19121	CAP	887	175-63-52401	CYLINDER GRP.
850	175-61-00026	YOKE IDLER	888	175-63-52402	CYLINDER GRP.
851	175-61-13964	CABLE	889	175-63-52421	ROT
852	175-61-15201	BUSHING	890	175-63-52422	ROD
853	175-63-02110	CYLINDER ASSY	891	175-63-52432	NUT
854	175-63-02111	CYLINDER ASSY	892	175-63-52541	CYLINDER
855	175-63-12352	RETAINER	893	175-63-52542	CYLINDER TILT
856	175-63-12540	BUSHING	894	175-63-52700	TILT CYLINDER
857	175-63-13102	CYLINDER GROUP	895	175-70-00514	BRACKET
858	175-63-13103	CYLINDER GROUP	896	175-70-00523	BRACKET
859	175-63-13120	ROD ASS	897	175-70-00541	BRACKET ASSY
860	175-63-13130	HEAD	898	175-70-00542	BRACKET ASSY
861	175-63-13131	HEAD	899	175-70-00543	BRACKET ASSY
862	175-63-13141	CYLINDER	900	175-70-12130	SCREW
863	175-63-13202	CYLINDER ASSY	901	175-70-13312	JOINT
864	175-63-13203	CYLINDER ASSY	902	175-70-13313	JOINT
865	175-63-13200	CYLINDER GROUP	903	175-70-13314	JOINT
866	175-63-13300	CYLINDER GROUP	904	175-70-21153	BRACKET
867	175-63-13400	CYLINDER GROUP	905	175-70-22141	SHAFT
868	175-63-13630	GLAND	906	175-70-23131	TRUNNION
869	175-63-22320	ROD	907	175-70-23133	TRUNNION
870	175-63-22341	CYLINDER	908	175-70-23180	CAP
871	175-63-22520	ROD	909	175-70-23222	PIN
872	175-63-22540	CYLINDER	910	175-70-23261	BRACKET
873	175-63-42221	ROD	911	175-70-23293	BALL-STUD-WELDED
874	175-63-42245	CYLINDER	912	175-71-00233	ARM

913	175-71-00321	BRACKET	951	176-76-61320	SHAFT
914	175-71-00361	PIN	952	177-50-11160	BUSHING
915	175-71-00461	BRACKET	953	178-30-12140	PLATE
916	175-71-11211	CAP	954	178-30-12150	PLATE
917	175-71-11272	BRACKET	955	178-30-12160	PLATE
918	175-71-11281	ROD	956	178-30-12161	PLATE
919	175-71-11482	CAP	957	178-30-12170	PLATE
920	175-71-11491	BOLT	958	178-30-12171	PLATE
921	175-71-11520	NUT	959	17A-03-41111	RADIATOR
922	175-71-21181	BRACKET	960	17A-03-41112	RADIATOR
923	175-71-21182	BRACKET	961	17A-03-41113	RADIATOR
924	175-71-21221	PIN	962	17A-06-17930	LAMP
925	175-71-21230	PLATE	963	17A-12-11151	BODY
926	175-71-21261	JOINT	964	17A-12-11161	PLATE
927	175-71-27841	BRACKET	965	17A-12-11171	PLATE
928	175-71-27842	BRACKET	966	17A-12-11211	SHAFT
929	175-71-31121	BRACKET	967	17A-12-11221	COUPLING
930	175-71-31131	BRACKET	968	17A-12-11260	WASHER
931	175-71-31183	ARM	969	17A-12-12111	COVER
932	175-71-31190	CAP	970	17A-12-15111	GAGE
933	175-71-31221	CAP	971	17A-15-18664	COUPLING
934	175-71-31280	CAP	972	17A-15-42521	PIN
935	175-71-31292	ARM	973	17A-15-42550	PIN
936	175-71-31293	ARM	974	17A-15-42570	WASHER
937	175-71-31311	BRACKET	975	17A-21-13181	GAUGE
938	175-71-31321	COVER	976	17A-21-43131	GAUGE
939	175-71-31331	COVER	977	17A-22-18110	SHAFT
940	175-71-31561	STUD BALL	978	17A-27-11151	BOSS SPR
941	175-71-31562	STUD BALL	979	17A-27-11152	BOSS SPR
942	175-71-31563	STUD BALL	980	17A-27-11241	PINION
943	175-71-41251	TRUNNION	981	17A-27-11251	GEAR PLANETARY
944	176-30-43111	BRACKET	982	17A-27-11611	GUARD
945	176-30-43121	BRACKET	983	17A-27-11621	GUARD
946	176-30-44110	YOKE IDLER	984	17A-27-41140	SHAFT
947	176-32-11151	PIN	985	17A-27-41141	SHAFT
948	176-32-11172	BUSHING	986	17A-27-41151	HUB
949	176-32-11192	PIN	987	17A-27-41160	CARRIER
950	176-32-11192	PIN	988	17A-27-41161	CARRIER

KOMATSU PART LIST



989	17A-27-41220	GEAR	1027	17A-30-47151	GUARD
990	17A-27-41230	HUB	1028	17A-30-48462	CYLINDER
991	17A-27-41241	GEAR	1029	17A-30-48481	NUT
992	17A-27-41251	GEAR	1030	17A-30-48492	CLAMP
993	17A-27-41260	GEAR	1031	17A-49-15130	STRAINER
994	17A-27-41280	SHAFT	1032	17A-50-00010	EQU LAZIER BAR
995	17A-27-41670	BOSS SPR	1033	17A-50-00011	EQU LAZIER BAR
996	17A-27-41671	BOSS SPR	1034	17A-50-00020	EQU LAZIER BAR
997	17A-30-00050	BOGIE	1035	17A-50-00021	EQU LAZIER BAR
998	17A-30-00051	BOGIE	1036	17A-50-00111	EQU LAZIER BAR
999	17A-30-00060	PIN ASSY	1037	17A-50-11111	PIVOT SHAFT
1000	17A-30-00061	PIN ASSY	1038	17A-50-11120	BUSHING
1001	17A-30-00360	PIN ASSY	1039	17A-50-11140	SEAL
1002	17A-30-12241	GUIDE	1040	17A-50-11130	BUSHING
1003	17A-30-14113	CASE	1041	17A-50-11151	PLATE
1004	17A-30-14141	COVER	1042	17A-50-11160	SPACER
1005	17A-30-14191	YOKE IDLER	1043	17A-50-11181	PLATE
1006	17A-30-14192	YOKE IDLER	1044	17A-50-11190	COVER
1007	17A-30-16111	BOGIE,OUTHER	1045	17A-50-11221	COVER
1008	17A-30-16121	BOGIE,INNER	1046	17A-50-11231	COVER
1009	17A-30-16131	PAD	1047	17A-50-11271	PLATE
1010	17A-30-16140	CAP	1048	17A-50-12111	EQU LAZIER BAR
1011	17A-30-16150	BOLT	1049	17A-50-12112	EQU LAZIER BAR
1012	17A-30-16331	CAP	1050	17A-50-12121	PIN
1013	17A-30-17122	BRACKET	1051	17A-50-12181	BUSHING
1014	17A-30-17141	PLATE	1052	17A-50-12270	BUSHING
1015	17A-30-17142	PLATE	1053	17A-50-12291	SEAL
1016	17A-30-17251	GUARD	1054	17A-50-12310	BUSHING
1017	17A-30-17261	GUARD	1055	17A-50-12331	BUSHING
1018	17A-30-17272	GUARD	1056	17A-50-12351	BUSHING
1019	17A-30-17282	GUARD	1057	17A-50-12391	PIN
1020	17A-30-43461	CYLINDER	1058	17A-50-12431	BUSHING
1021	17A-30-46121	BOGIE	1059	17A-50-41210	BUSHING
1022	17A-30-46202	PIN	1060	17A-50-41110	EQU LAZIER BAR
1023	17A-30-46330	CAP	1061	17A-50-41111	EQU LAZIER BAR
1024	17A-30-46331	CAP	1062	17A-50-41190	SPACER
1025	17A-30-47131	GUIDE	1063	17A-50-42120	PIN
1026	17A-30-47141	GUARD	1064	17A-50-42131	BUSHING

1065	17A-50-42140	PIN	1103	17A-71-11341	BRACKET
1066	17A-50-42151	BEARING	1104	17A-71-12131	BRACKET
1067	17A-50-42211	BUSHING	1105	17A-71-12321	BRACKET
1068	17A-54-46120	CUSHION	1106	17A-71-12231	BRACKET
1069	17A-54-46130	CUSHION	1107	17A-71-12241	BRACKET
1070	17A-61-11111	YOKE	1108	17A-71-12261	TRUNNION
1071	17A-61-11211	YOKE	1109	17A-71-12262	TRUNNION
1072	17A-61-11120	CAP	1110	17A-71-12280	CAP
1073	17A-60-43110	YOKE	1111	17A-71-12291	COVER
1074	17A-61-43210	YOKE	1112	17A-71-12361	WASHER
1075	17A-61-49122	CAP	1113	17A-71-12481	BRACKET
1076	17A-63-02110	CYLINDER	1114	17A-71-12521	ARM
1077	17A-63-02130	TILT	1115	17A-71-12541	CAP
1078	17A-63-02140	CYLINDER ASSY	1116	17A-71-12611	BRACKET
1079	17A-63-02141	CYLINDER ASSY	1117	17A-71-21710	PIN
1080	17A-63-02160	CYLINDER ASSY	1118	17A-71-21720	PLATE
1081	17A-63-02161	CYLINDER ASSY	1119	17A-71-45321	BRACKET
1082	17A-63-02190	TILT	1120	17A-71-45331	BRACKET
1083	17A-63-42140	CYLINDER	1121	17A-71-45421	BRACKET
1084	17A-63-42141	CYLINDER	1122	17A-71-45431	BRACKET
1085	17A-63-42142	CYLINDER	1123	17A-71-45460	CAP
1086	17A-63-43140	CYLINDER	1124	17A-71-45490	LOCK
1087	17A-63-43141	CYLINDER	1125	17A-71-45511	ARM
1088	17A-63-43142	CYLINDER	1126	17A-71-45521	JOINT WELDED
1089	17A-63-52140	CYLINDER	1127	17A-71-45531	CAP
1090	17A-63-53140	CYLINDER	1128	17A-71-45541	TRUNNION
1091	17A-63-X2110	CYLINDER ASS	1129	17A-71-45591	TRUNNION
1092	17A-63-X2120	CYLINDER ASS	1130	17A-71-45592	TRUNNION
1093	17A-63-X2160	CYLINDER ASS	1131	17A-71-45970	TRUNNION
1094	17A-63-X2161	CYLINDER ASS	1132	17A-Z11-2540	BLADE WIPER
1095	17A-63-X2170	CYLINDER ASS	1133	17A-Z11-2581	BLADE
1096	17A-63-X2171	CYLINDER ASS	1134	17M-27-21411	GEAR
1097	17A-63-XF190	CYLINDER ASS	1135	17M-27-41230	GEAR
1098	17A-63-XF191	CYLINDER ASS	1136	17M-30-00411	CASE ASS
1099	17A-71-11311	BRACKET	1137	17M-30-00561	BOGIE
1100	17A-71-11312	BRACKET	1138	17M-30-00630	BOGIE
1101	17A-71-11321	BRACKET	1139	17M-30-26620	BUSHING
1102	17A-71-11331	BRACKET	1140	17M-30-44290	PLATE

KOMATSU PART LIST



1141	17M-30-51401	CASE	1179	17M-71-41190	BRACKET
1142	17M-30-51430	SPACER	1180	17M-71-41370	TRUNNION
1143	17M-30-51480	CAP	1181	17M-71-41411	BRACKET
1144	17M-30-51540	GUARD	1182	17M-71-41440	ARM
1145	17M-30-51550	GUARD	1183	17M-71-41460	PIN
1146	17M-30-52140	GUIDE	1184	17M-71-41470	PLATE
1147	17M-30-54111	YOKE	1185	17M-71-41920	COVER
1148	17M-30-54120	PLATE	1186	17M-71-41951	BRACKET
1149	17M-30-54220	PILOT	1187	17M-71-41971	CAP
1150	17M-30-54230	PILOT	1188	17M-71-42120	BRACKET
1151	17M-30-54241	SPACER	1189	17M-71-42131	BRACKET
1152	17M-30-54250	BOLT	1190	17M-71-42411	BRACKET
1153	17M-30-54261	PISTON	1191	180-50-12110	PAD
1154	17M-30-54281	CYLINDER	1192	195-03-11125	RADIATOR
1155	17M-30-56130	PAD	1193	195-03-11897	PULLEY
1156	17M-30-56111	BOGIE	1194	195-13-11143	GEAR
1157	17M-30-56112	BOGIE	1195	195-13-11212	CASE
1158	17M-30-56122	BOGIE	1196	195-13-11654	SHAFT
1159	17M-30-56151	BOGIE	1197	195-13-11662	FLANGE
1160	17M-30-56341	COVER	1198	195-13-11663	FLANGE
1161	17M-30-56201	PIN ASSY	1199	195-13-11666	FLANGE
1162	17M-30-57131	GUIDE	1200	195-13-11730	SPACER
1163	17M-50-00111	EQUŁAZIER BAR	1201	195-13-12112	STATOR
1164	17M-50-00112	EQUŁAZIER BAR	1202	195-13-12122	RACE
1165	17M-50-22120	PIVOT SHAFT	1203	195-13-12524	SHAFT
1166	17M-50-22210	BUSHING	1204	195-13-13420	TORQUE SCREEN
1167	17M-50-22220	BUSHING	1205	195-15-00070	HOUSING
1168	17M-50-22260	BOLT	1206	195-15-00071	HOUSING
1169	17M-50-24350	RING	1207	195-15-00081	HOUSING
1170	17M-50-41110	EQUŁAZIER BAR	1208	195-15-00082	HOUSING
1171	17M-50-41170	SPACER	1209	195-15-00090	HOUSING
1172	17M-50-41111	EQUŁAZIER BAR	1210	195-15-00091	HOUSING
1173	17M-50-41120	PIN	1211	195-15-00110	HOUSING
1174	17M-50-41161	BEARING	1212	195-15-00111	HOUSING
1175	17M-50-41221	COVER	1213	195-15-00120	HOUSING
1176	17M-50-49120	PIN	1214	195-15-11141	HOUSING
1177	17M-71-21380	JOINT	1215	195-15-11151	HOUSING
1178	17M-71-41171	BRACKET	1216	195-15-11152	HOUSING

1217	195-15-11161	HOUSING	1255	195-15-19230	CARRIER
1218	195-15-11171	HOUSING	1256	195-20-00011	SHAFT ASS
1219	195-15-11181	HOUSING	1257	195-20-11131	YOKE
1220	195-15-12112	SHAFT	1258	195-27-11140	PIN
1221	195-15-12120	GEAR	1259	195-27-11215	FLANGE
1222	195-15-12151	COUPLING	1260	195-27-11216	FLANGE
1223	195-15-12152	COUPLING	1261	195-27-11217	FLANGE
1224	195-15-12212	SHAFT	1262	195-27-11236	PINION
1225	195-15-12213	SHAFT	1263	195-27-11237	PINION
1226	195-15-12220	GEAR	1264	195-27-11242	GEAR FINAL DRIVE
1227	195-15-12230	GEAR	1265	195-27-11252	HUB
1228	195-15-12320	CARRIER	1266	195-27-11253	HUB
1229	195-15-12321	CARRIER	1267	195-27-11282	ANCHOR
1230	195-15-12330	CARRIER	1268	195-27-11312	GUARD
1231	195-15-12331	CARRIER	1269	195-27-11321	GUARD
1232	195-15-12364	CARRIER	1270	195-27-11322	GUARD
1233	195-15-12450	GEAR	1271	195-27-12112	SHAFT
1234	195-15-12460	GEAR	1272	195-27-12121	GEAR
1235	195-15-12470	GEAR	1273	195-27-12152	CARRIER
1236	195-15-12480	GEAR	1274	195-27-12153	CARRIER
1237	195-15-12490	GEAR	1275	195-27-12154	CARRIER
1238	195-15-12512	SHAFT	1276	195-27-12155	CARRIER
1239	195-15-12522	SHAFT	1277	195-27-12225	DRUM
1240	195-15-12532	SHAFT	1278	195-27-12226	DRUM
1241	195-15-12543	SHAFT	1279	195-27-12271	SUPPORT
1242	195-15-12612	GEAR	1280	195-27-12272	SUPPORT
1243	195-15-12621	GEAR	1281	195-27-12280	BUSHING
1244	195-15-12632	GEAR	1282	195-27-12281	BUSHING
1245	195-15-12641	GEAR	1283	195-27-12282	BUSHING
1246	195-15-12651	GEAR	1284	195-27-12290	COLLAR
1247	195-15-12665	GEAR	1285	195-27-12291	COLLAR
1248	195-15-12670	GEAR	1286	195-27-12314	SHAFT
1249	195-15-12731	PISTON	1287	195-27-12315	SHAFT
1250	195-15-12732	PISTON	1288	195-27-12372	GEAR
1251	195-15-12791	PISTON	1289	195-27-12381	SHAFT
1252	195-15-13232	GEAR	1290	195-27-12412	WASHER
1253	195-15-19210	CARRIER	1291	195-27-12422	FLANGE
1254	195-15-19220	CARRIER	1292	195-27-12660	GUARD

KOMATSU PART LIST



1293	195-27-12661	GUARD	1331	195-30-17960	WASHER
1294	195-27-31151	GUARD	1332	195-30-32300	PIN
1295	195-27-31161	GUARD	1333	195-30-34121	BUSHING
1296	195-27-32162	BUSHING	1334	195-30-62141	CAP
1297	195-27-34340	COVER	1335	195-30-62100	PIN
1298	195-27-34350	COVER	1336	195-30-62400	PIN
1299	195-30-11310	BUSHING	1337	195-30-66131	PAD
1300	195-30-11341	CAP	1338	195-30-66190	PAD
1301	195-30-11342	CAP	1339	195-30-67230	GUIDE
1302	195-30-12154	GUARD	1340	195-30-67410	GUIDE
1303	195-30-12164	GUARD	1341	195-30-69400	PIN ASSY
1304	195-30-12190	STRIP	1342	195-30-66520	BOGIE
1305	195-30-12191	STRIP	1343	195-30-69131	PAD
1306	195-30-12192	STRIP	1344	195-30-66531	PAD
1307	195-30-12193	STRIP	1345	195-38-11510	TUBE
1308	195-30-12210	STRIP	1346	195-38-11531	TUBE
1309	195-30-12211	STRIP	1347	195-38-11541	TUBE
1310	195-30-12212	STRIP	1348	195-43-25180	CABLE
1311	195-30-12213	STRIP	1349	195-49-11211	SCREEN
1312	195-30-12214	GUARD	1350	195-49-11221	MAGNET ASSM.
1313	195-30-12220	GUARD	1351	195-49-13740	COVER
1314	195-30-12221	GUARD	1352	195-49-35122	SCREEN
1315	195-30-12222	GUARD	1353	195-49-35141	MAGNET ASSM.
1316	195-30-12224	GUARD	1354	195-50-00025	EQU LAZIER BAR
1317	195-30-12230	STRIP	1355	195-50-00026	EQU LAZIER BAR
1318	195-30-12231	STRIP	1356	195-50-11122	BUSHING
1319	195-30-12232	STRIP	1357	195-50-11133	SUPPORT
1320	195-30-12233	GUARD	1358	195-50-11231	SEAT
1321	195-30-13250	SHAFT	1359	195-50-11312	PIN
1322	195-30-13251	SHAFT	1360	195-50-11330	BUSHING
1323	195-30-13430	GUIDE	1361	195-50-00080	EQU LAZIER BAR
1324	195-30-13431	GUIDE IDLER	1362	195-63-01110	CYLINDER ASSY
1325	195-30-13441	GUIDE	1363	195-63-01120	CYLINDER ASSY
1326	195-30-14123	SHAFT	1364	195-63-01130	CYLINDER ASS
1327	195-30-14151	WASHER	1365	195-63-12640	BUSHING
1328	195-30-14170	CYLINDER	1366	195-63-13102	CYLINDER-ASSY
1329	195-30-14171	CYLINDER	1367	195-63-13103	CYLINDER ASSY
1330	195-30-14190	PISTON	1368	195-63-13120	ROD

1369	195-63-13121	ROD	1407	195-71-32340	CAP
1370	195-63-13130	HEAD	1408	195-71-51191	TRUNNION
1371	195-63-13131	HEAD	1409	195-71-61380	JOINT
1372	195-63-13142	CYLINDER	1410	195-71-74231	CAP
1373	195-63-13202	CYLINDER ASSY	1411	195-71-74250	BUSHING
1374	195-63-13203	CYLINDER ASSY	1412	195-911-8991	COMPRESSOR
1375	195-63-13240	CYLINDER	1413	196-03-00071	RADIATOR
1376	195-63-13700	CYLINDER-ASSY	1414	198-21-11490	FLANCE
1377	195-63-13800	CYLINDER-ASSY	1415	198-30-32800	PIN
1378	195-63-22171	CAP	1416	198-30-32900	PIN
1379	195-63-42133	HEAD TILT	1417	198-30-66190	COLLAR
1380	195-63-52122	TILT ROD	1418	198-30-56132	PAD
1381	195-63-52160	BUSHING	1419	198-30-66120	PAD
1382	195-63-52162	BUSHING	1420	198-30-67131	GUIDE
1383	195-63-52332	HEAD CYLINDER	1421	198-50-11130	PAD
1384	195-63-52470	GLAND	1422	19M-04-11220	CAP
1385	195-63-52500	CYLINDER ASSY	1423	19M-54-11770	WASHER
1386	195-63-52602	CYLINDER ASSY	1424	203-60-56250	STRANIER
1387	195-63-52622	CYLINDER	1425	205-04-71140	STRANIER
1388	195-63-82560	PISTON	1426	205-27-71531	GEAR
1389	195-71-00071	BRACKET	1427	205-27-71570	SPACER
1390	195-71-00072	BRACKET	1428	205-27-71582	PIN
1391	195-71-00212	BRACKET	1429	205-27-71630	HUB GEAR
1392	195-71-11274	BRACKET	1430	205-60-51270	STRANIER
1393	195-71-11344	TRUNNION	1431	205-70-65762	BUSHING
1394	195-71-11346	TRUNNION	1432	205-70-66550	BUSHING
1395	195-71-11484	CAP	1433	205-70-67150	BUSHING
1396	195-71-11810	TRUNNION WELDED	1434	205-70-71360	BUSHING
1397	195-71-11820	TRUNNION WELDED	1435	205-70-72130	BUSHING
1398	195-71-21180	JOINT	1436	205-70-73160	PIN
1399	195-71-21181	JOINT	1437	205-70-73180	BUSHING
1400	195-71-21281	JOINT	1438	205-70-73270	PIN
1401	195-71-21311	BALL STUD	1439	206-03-22411	RADIATOR
1402	195-71-31180	BRACKET	1440	206-03-51110	RADIATOR
1403	195-71-31211	BRACKET	1441	206-03-51111	RADIATOR
1404	195-71-31370	CAP	1442	206-26-71520	WASHER
1405	195-71-31381	COVER	1443	206-27-44112	GEAR
1406	195-71-31412	COVER	1444	206-27-44132	GEAR

KOMATSU PART LIST



1445	206-70-51190	PIN	1483	208-30-74120	SHAFT
1446	206-70-53140	PIN	1484	208-70-31172	PIN
1447	206-70-53150	BUSHING	1485	208-70-33130	PIN
1448	206-70-71381	BUSHING	1486	208-70-33140	PIN
1449	207-03-71110	RADIATOR	1487	208-70-51190	BUSHING
1450	207-03-75120	RADIATOR	1488	208-70-51440	BUSHING
1451	207-03-75121	RADIATOR	1489	208-70-61220	PIN
1452	207-27-20270	HEAD	1490	209-03-41210	RADIATOR
1453	207-27-52270	SPACER	1491	209-03-71110	RADIATOR
1454	207-27-71250	WASHER	1492	209-03-77100	RADIATOR
1455	207-30-71441	CYLINDER ASSY	1493	209-72-51161	PIN
1456	207-30-74120	SHAFT	1494	209-38-12470	ELEMENT
1457	207-43-17220	CABLE	1495	20G-22-23821	ARM ASSY
1458	207-43-23520	CABLE	1496	20G-26-00020	CARRIER
1459	207-43-34110	CABLE	1497	20G-26-11161	GEAR
1460	207-43-51410	CABLE	1498	20G-26-11231	PIN
1461	207-60-51200	STRANIER	1499	20G-26-21111	GEAR
1462	207-60-61250	STRANIER	1500	20Y-03-D1160	RADIATOR
1463	207-63-76170	BUSHING	1501	20Y-03-14120	RADIATOR
1464	207-70-12161	BUSHING	1502	20Y-03-31111	RADIATOR
1465	207-70-31172	PIN	1503	20Y-03-41651	RADIATOR
1466	207-70-31222	BUSHING	1504	20Y-43-17220	CABLE
1467	207-70-32140	BUSHING	1505	20Y-43-51410	CABLE
1468	207-70-32150	BUSHING	1506	20Y-60-21311	STRANIER
1469	207-70-33140	PIN	1507	20Y-60-31140	STRANIER
1470	207-70-33160	BUSHING	1508	20Y-70-32361	BUSHING
1471	207-70-71162	BUSHING	1509	20Y-70-32410	BUSHING
1472	207-70-73210	PIN	1510	20Y-979-3111	COMP
1473	207-70-73240	BUSHING	1511	21M-03-21110	RADIATOR
1474	207-70-73250	BUSHING	1512	21N-01-31330	PRECLEANER
1475	208-03-51111	RADIATOR	1513	21N-03-37700	RADIATOR
1476	208-03-61350	RADIATOR	1514	22W-15-21140	PLATE
1477	208-03-61610	RADIATOR	1515	22W-15-21270	PIM
1478	208-03-68350	RADIATOR	1516	22W-15-21280	PIM
1479	208-03-71110	RADIATOR	1517	22W-15-22212	GEAR
1480	208-03-75110	RADIATOR	1518	22W-15-22230	GEAR
1481	208-30-54160	NUT	1519	22W-15-22231	GEAR
1482	208-30-71440	CYLINDER ASSY	1520	22W-15-22242	GEAR

1521	22W-15-22620	GEAR	1559	232-60-57420	FLANCE
1522	22W-15-22390	BUSHING	1560	232-70-00120	SHIM
1523	22W-15-22410	GEAR	1561	232-70-00140	SHIM
1524	22W-15-22411	GEAR	1562	232-70-11320	SHIM
1525	22W-15-22420	GEAR	1563	232-70-12420	GUIDE
1526	22W-15-22421	GEAR	1564	232-70-12430	GUIDE
1527	22W-15-22440	GEAR	1565	232-70-52260	GUIDE
1528	22W-15-22441	GEAR	1566	232-70-52270	GUIDE
1529	22W-15-22510	SHAFT	1567	232-70-53132	YOKE
1530	22W-15-22550	PIM	1568	232-70-53133	YOKE
1531	22W-15-22570	WASHER	1569	232-70-53134	YOKE
1532	22W-15-29710	BUSHING	1570	232-70-53141	BUSHING
1533	232-22-55110	GASKET	1571	232-70-53271	CAP
1534	232-27-31450	BUSHING	1572	232-70-53280	BOLT
1535	232-27-51410	KNUCKLE ARM	1573	232-70-54141	WHEEL
1536	232-27-51411	KNUCKLE ARM	1574	232-70-54430	WASHER
1537	232-32-11221	BOOT	1575	232-70-54440	BUSHING
1538	232-32-11322	VALVE	1576	232-70-54450	WASHER
1539	232-32-11460	SPRING	1577	232-70-54470	LOCK
1540	232-32-21340	SPRING	1578	232-71-11422	BUSHING
1541	232-32-53131	SHOE ASSY	1579	232-735-1250	GUIDE
1542	232-32-53160	SPRING	1580	232-785-1291	SHANK
1543	232-32-53170	SPRING	1581	232-843-1510	CYLINDDER
1544	232-32-53180	SCREW ASS	1582	233-32-11460	SPRING
1545	232-32-53230	SEAT	1583	233-32-21260	LINING
1546	232-32-56120	PIM	1584	233-32-21290	PIM
1547	232-32-53220	SPRING	1585	233-32-21340	SPRING
1548	232-32-56300	WHEEL	1586	233-70-00260	SHIM
1549	232-43-56220	CABLE	1587	233-70-25150	SPACER
1550	232-43-56250	CABLE	1588	233-71-13354	GEAR
1551	232-43-57180	BUSHING	1589	234-03-11210	RADIATOR
1552	232-46-13170	SHIM	1590	234-03-12110	RADIATOR
1553	232-46-53210	BUSHING	1591	234-71-13182	SHAFT
1554	232-46-53211	BUSHING	1592	234-71-13183	SHAFT
1555	232-60-54702	JOINT	1593	234-71-13190	BUSHING
1556	232-60-54711	BODY	1594	234 71-13253	PIM
1557	232-60-54720	FLANGE	1595	234-785-1121	POINT
1558	232-60-54730	PLATE	1596	234-12-31110	DISK

KOMATSU PART LIST



1597	234-22-00130	BEVEL GEAR	1635	234-27-31610	ROD TIE L.H
1598	234-22-32100	BEVEL GEAR	1636	234-27-31620	ROD TIE R.H
1599	234-22-32150	GEAR	1637	234-27-31660	JOINT
1600	234-22-32130	GEAR	1638	234-27-31670	NUT
1601	234-22-32131	GEAR	1639	234-27-31680	NUT
1602	234-22-32132	GEAR	1640	234-27-31690	END ROD
1603	234-22-35131	GEAR	1641	234-27-31810	PIN
1604	234-22-35132	GEAR	1642	234-27-31820	BUSHING
1605	234-22-51110	GEAR	1643	234-27-31830	PIN
1606	234-22-51111	GEAR	1644	234-27-31840	PIN
1607	234-22-51120	GEAR	1645	234-27-31850	BUSHING
1608	234-27-32660	SERVICE KIT	1646	234-27-31880	BUSHING
1609	234-27-32661	SERVICE KIT	1647	234-27-31910	PIN
1610	234-27-32670	SERVICE KIT	1648	234-27-31920	BUSHING
1611	234-27-32671	SERVICE KIT	1649	234-27-31930	BUSHING
1612	234-22-35150	GEAR	1650	234-27-31940	BUSHING
1613	234-23-13210	NUT	1651	234-27-31961	PLUG
1614	234-27-00220	HOUSING ASSY LH	1652	234-27-32410	HOUSING L.H
1615	234-27-00230	HOUSING ASSY RH	1653	234-27-32420	HOUSING R.H
1616	234-27-00310	LEANING ROD	1654	234-27-32430	BRACKET
1617	234-27-00320	PITMAN ARM ASSY	1655	234-27-32440	PIN
1618	234-27-00321	PITMAN ARM ASSY	1656	234-27-32590	STUD BALL
1619	234-27-31120	LEANING ROD	1657	234-27-33590	STUD BALL
1620	234-27-31150	SHAFT HUB	1658	234-30-13420	RING
1621	234-27-31160	HOUSING LH	1659	234-30-13430	SEGMAN
1622	234-27-31170	HOUSING RH	1660	234-32-11160	SPRING
1623	234-27-31190	BRACKET	1661	234-32-21220	COLLAR
1624	234-27-31210	CAP	1662	234-32-21320	PISTON
1625	234-27-31220	SPACER	1663	234-32-21330	CUP
1626	234-27-31240	PIN	1664	234-32-21340	SPRING
1627	234-27-31290	SPACER	1665	234-43-16152	CABLE
1628	234-27-31410	ARM.PITMAN	1666	234-43-18710	PIN
1629	234-27-31411	ARM,PITMAN	1667	234-63-13001	CYLINDER ASS
1630	234-27-31430	BALL STUD	1668	234-63-13021	ROD ASS
1631	234-27-31431	BALL STUD	1669	234-63-13041	CYLINDER
1632	234-27-31433	BALL	1670	234-63-76002	CYLINDER ASSY.STEERING
1633	234-27-31450	BUSHING	1671	234-63-76003	CYLINDER ASSY.STEERING
1634	234-27-31510	PIN	1672	234-63-76004	CYLINDER ASSY.STEERING

1673	234-63-76021	ROD PISTON	1711	235-15-22210	GEAR
1674	234-63-76022	ROD PISTON	1712	235-25-11360	PLATE
1675	234-63-76023	ROD PISTON	1713	236-46-13380	BUSHING
1676	234-63-76041	CYLINDER	1714	237-43-14190	HOSE
1677	234-63-76600	CYLINDER ASSY.STEERING	1715	238-03-11461	HOSE
1678	234-70-12251	GUIDE	1716	238-03-11471	HOSE
1679	234-70-12261	GUIDE	1717	238-15-12810	PLATE
1680	234-70-32230	BIT	1718	238-15-15130	SEAL
1681	234-70-32240	BIT	1719	238-22-11890	BUSHING
1682	234-70-33180	GUIDE	1720	238-25-15130	SEAL
1683	234-70-33190	GUIDE	1721	238-25-16350	BOLT
1684	234-70-33260	ROD	1722	238-45-11310	ROD
1685	234-70-33370	ADJUSTER ASSY L.H	1723	238-45-11320	ROD
1686	234-70-33380	ADJUSTER ASSY RH	1724	238-45-11330	ROD
1687	234-70-33360	ADJUSTER ASSY RH	1725	238-63-12301	CYLINDER
1688	234-70-12151	BLOCK	1726	238-63-12302	CYLINDER
1689	234-70-35130	SHAFT	1727	238-63-12320	ROD
1690	234-70-35131	SHAFT	1728	238-63-12340	CYLINDER
1691	234-70-35140	GEAR	1729	238-63-X1110	CYLINDER ASSY
1692	234-70-35141	GEAR	1730	238-63-X1120	CYLINDER ASSY
1693	234-70-35150	WASHER	1731	238-70-11210	JOINT
1694	234-70-35160	GEAR	1732	273-24-11134	SHAFT
1695	234-70-35180	GEAR	1733	273-24-11172	HUB
1696	234-70-35330	SHAFT	1734	273-24-11334	GEAR
1697	234-70-35331	SHAFT	1735	273-24-11363	PIN
1698	234-70-35410	WASHER	1736	273-24-11372	BEARING
1699	234-71-13223	GEAR	1737	273-24-11384	GEAR
1700	234-71-13224	GEAR	1738	273-24-11412	WASHER
1701	234-71-13225	GEAR	1739	273-24-11434	CARRIER
1702	234-71-13243	JOINT	1740	273-43-51210	CABLE
1703	234-71-13244	JOINT	1741	23A 43-19130	SHAFT
1704	234-71-13442	PIN	1742	23A 43-19140	BRACKET
1705	234-71-13443	PIN	1743	23A-03-11641	RADIATOR
1706	234-71-13650	FLANGE	1744	23A-12-12110	DISC
1707	234-71-13660	GEAR	1745	23A-12-12120	CUPLING
1708	235 -27-11750	BOOT	1746	23A-15-00150	HOUSING
1709	235-15-12570	WASHER	1747	23A-15-00151	HOUSING
1710	235-15-12590	WASHER	1748	23A-15-11120	PLATE

KOMATSU PART LIST



1749	23A-15-11150	HOUSING	1787	23A-15-18250	GEAR
1750	23A-15-11160	HOUSING	1788	23A-15-18260	GEAR-28 TEETH
1751	23A-15-11161	HOSING	1789	23A-15-18310	SHAFT
1752	23A-15-11171	HOUSING	1790	23A-15-18710	BEARING
1753	23A-15-11172	HOUSING	1791	23A-15-19210	RING
1754	23A-15-11173	HOUSING	1792	23A-16-11160	TUBE
1755	23A-15-11181	HOUSING	1793	23A-22-05010	KIT
1756	23A-15-11210	CAGE	1794	23A-22-05011	KIT
1757	23A-15-12110	SHAFT	1795	23A-22-11120	CASE
1758	23A-15-12221	GEAR	1796	23A-22-11130	CAGE
1759	23A-15-12270	HUB	1797	23A-22-11131	CAGE
1760	23A-15-12280	HUB	1798	23A-22-11180	COVER
1761	23A-15-12310	CARRIER	1799	23A-22-11190	COUPLING
1762	23A-15-12320	CARRIER	1800	23A-22-11200	BEVEL GEAR
1763	23A-15-12321	CARRIER	1801	23A-22-11250	CAGE
1764	23A-15-12330	CARRIER	1802	23A-22-11371	SHAFT
1765	23A-15-12410	GEAR	1803	23A-22-11402	CAGE ASSY
1766	23A-15-12451	GEAR	1804	23A-22-11403	CAGE ASSY
1767	23A-15-12530	PIN	1805	23A-22-11410	SPACER
1768	23A-15-12560	WASHER	1806	23A-22-11420	GEAR
1769	23A-15-12610	GEAR	1807	23A-22-11450	BUSHING
1770	23A-15-12611	GEAR	1808	23A-22-11460	WASHER
1771	23A-15-12620	GEAR RING	1809	23A-22-11510	TUBE
1772	23A-15-12630	GEAR RING	1810	23A-22-11590	SPACER
1773	23A-15-12640	GEAR RING	1811	23A-22-11630	SHAFT
1774	23A-15-12650	RING	1812	23A-22-11631	SHAFT
1775	23A-15-12660	GEAR	1813	23A-22-11640	SHAFT
1776	23A-15-12710	PISTON	1814	23A-22-11641	SHAFT
1777	23A-15-12740	PISTON	1815	23A-22-11900	CUL ASSY
1778	23A-15-12741	PISTON	1816	23A-22-11910	CLUTCH DRIVER
1779	23A-15-12751	PISTON	1817	23A-22-11920	RING
1780	23A-15-12752	PISTON	1818	23A-22-11930	SPIDER
1781	23A-15-12760	PISTON	1819	23A-22-11950	GEAR
1782	23A-15-12761	PISTON	1820	23A-23-05030	KIT
1783	23A-15-12770	PISTON	1821	23A-23-11150	GEAR
1784	23A-15-18210	SHAFT	1822	23A-23-11210	CAGE
1785	23A-15-18220	GEAR	1823	23A-23-11211	CAGE
1786	23A-15-18230	GEAR	1824	23A-23-11220	SHAFT

1825	23A-23-11221	SHAFT	1863	23A-27-31350	PIN
1826	23A-23-11222	SHAFT	1864	23A-27-31520	PIN
1827	23A-23-11230	SHAFT	1865	23A-32-11000	BRAKE ASSY
1828	23A-23-11231	SHAFT	1866	23A-32-11130	NUT
1829	23A-23-11232	SHAFT	1867	23A-32-11140	WASHER
1830	23A-23-11240	DRUM	1868	23A-32-11150	ADJUST GEAR ASSY
1831	23A-23-11241	DRUM	1869	23A-32-11160	NUT
1832	23A-23-11242	DRUM	1870	23A-32-11170	GEAR
1833	23A-23-11290	SPROCKET	1871	23A-32-11180	YOKE
1834	23A-23-11500	CHAIN ASSY	1872	23A-32-11190	YOKE
1835	23A-27-11130	HUB	1873	23A-32-11230	SHOE ASSY
1836	23A-27-11131	HUB	1874	23A-32-11231	SHOE ASSY
1837	23A-27-11141	HOUSING	1875	23A-32-11240	SHOE
1838	23A-27-11151	HOUSING	1876	23A-32-11250	PLATE
1839	23A-27-11160	BRACKET	1877	23A-32-11260	PIM
1840	23A-27-11231	ROD	1878	23A-32-12110	DRUM
1841	23A-27-11250	PIN	1879	23A-40-05010	KIT
1842	23A-27-11260	WASHER	1880	23A-40-05110	KIT
1843	23A-27-11270	SPACER	1881	23A-40-12450	TUBE
1844	23A-27-11281	BEARING	1882	23A-43-05010	KIT
1845	23A-27-11310	PIN	1883	23A-43-05020	KIT
1846	23A-27-11330	PIN	1884	23A-43-12160	CABLE
1847	23A-27-11340	HOLDER	1885	23A-43-13110	BOOSTER AND MASTER CYLINDER
1848	23A-27-11350	SHAFT	1886	23A-43-13111	BOOSTER AND MASTER CYLINDER
1849	23A-27-11360	PLUG	1887	23A-43-13210	CYLINDER ASS
1850	23A-27-11370	COLLAR	1888	23A-43-13211	CYLINDER ASS
1851	23A-27-11380	COLLAR	1889	23A-43-13330	CYLINDER
1852	23A-27-11390	BUSHING	1890	23A-43-14110	TUBE
1853	23A-27-11520	PIN	1891	23A-43-14120	TUBE
1854	23A-27-11530	PIN	1892	23A-43-14210	TUBE
1855	23A-27-11610	BUSHING	1893	23S-43-14220	TUBE
1856	23A-27-11620	BUSHING	1894	23A-43-15120	CABLE
1857	23A-27-11630	BUSHING	1895	23A-43-18290	JOINT
1858	23A-27-11640	WASHER	1896	23A-43-18320	PLATE
1859	23A-27-12150	HOUSING	1897	23A-43-18360	PIM
1860	23A-27-31130	HOUSING	1898	23A-43-19130	SHAFT
1861	23A-27-31140	HOUSING	1899	23A-43-19140	SHAFT
1862	23A-27-31150	HOUSING	1900	23A-43-19150	CABLE

KOMATSU PART LIST



1901	23A-45-11160	CABLE	1939	23A-70-13130	ADJUSTER
1902	23A-45-11161	CABLE	1940	23A-70-13160	ADJUSTER
1903	23A-45-12160	CABLE	1941	23A-70-13190	PIN
1904	23A-46-11370	PIM	1942	23A-70-14210	BUSHING
1905	23A-46-11371	PIM	1943	23A-70-14220	BUSHING
1906	23A-46-12520	CAP	1944	23A-70-15110	CASE
1907	23A-63-12101	BLADE LIFT CYLINDER	1945	23A-70-15120	COVER
1908	23A-63-12120	CYLINDER ROD	1946	23A-70-15140	SHAFT
1909	23A-63-12140	CYLINDER	1947	23A-70-15150	BUSHING
1910	23A-63-22101	CYLINDER ASSY.	1948	23A-70-15160	BUSHING
1911	23A-63-22120	ROD	1949	23A-70-15170	WORM
1912	23A-63-22140	CYLINDER	1950	23A-70-15180	PLATE
1913	23A-63-52102	CYLINDER ASSY.	1951	23A-70-15210	HOUSING
1914	23A-63-52121	ROD	1952	23B-15-22510	SHAFT
1915	23A-63-52141	CYLINDER	1953	23B-15-12450	GEAR
1916	23A-63-62101	CYLINDER	1954	23B-15-00130	HOUSING
1917	23A-63-62102	CYLINDER ASSY	1955	23B-15-00131	HOUSING
1918	23A-63-62120	ROD	1956	23B-15-00140	SHAFT
1919	23A-63-62140	CYLINDER	1957	23B-15-00160	PLATE
1920	23A-63-62202	CYLINDER ASSY	1958	23B-15-00170	SHAFT
1921	23A-63-X1210	CYLINDER ASSY	1959	23B-15-00230	HOUSING
1922	23A-63-X1220	CYLINDER ASSY	1960	23B-15-00231	HOUSING
1923	23A-63-X1230	CYLINDER ASSY	1961	23B-15-00240	CARRIER-ALONE
1924	23A-63-X1280	CYLINDER ASSY	1962	23B-15-11120	HOUSING
1925	23A-63-X1290	CYLINDER ASSY	1963	23B-15-11150	HOUSING
1926	23A-63-Z1210	CYLINDER ASSY	1964	23B-15-11161	HOUSING
1927	23A-63-Z1220	CYLINDER ASSY	1965	23B-15-11172	HOUSING
1928	23A-63-Z1230	CYLINDER ASSY	1966	23B-15-11181	CAGE
1929	23A-63-Z1280	CYLINDER ASSY	1967	23B-15-11210	CAGE
1930	23A-63-Z1290	CYLINDER ASSY	1968	23B-15-12120	SHAFT
1931	23A-70-00010	BRACKET ASSY	1969	23B-15-12131	SHAFT
1932	23A-70-01030	GEAR ASSY	1970	23B-15-12220	GEAR
1933	23A-70-01031	GEAR ASSY	1971	23B-15-12230	GEAR
1934	23A-70-01050	GEAR ASSY	1972	23B-15-12270	HUB
1935	23A-70-01051	GEAR ASSY	1973	23B-15-12280	HUB
1936	23A-70-11230	GUIDE	1974	23B-15-12311	CARRIER
1937	23A-70-12131	SHAFT	1975	23B-15-12320	CARRIER
1938	23A-70-13120	ADJUSTER	1976	23B-15-12321	CARRIER

1977	23B-15-12340	CARRIER	2015	23B-22-11240	CAGE
1978	23B-15-12360	CARRIER	2016	23B-22-11250	CAGE
1979	23B-15-12420	GEAR	2017	23B-22-11300	CLAMP
1980	23B-15-12530	SHAFT	2018	23B-22-11301	CLAMP
1981	23B-15-12550	SHAFT	2019	23B-22-11302	CLAMP
1982	23B-15-12611	RING	2020	23B-22-11340	SHAFT
1983	23B-15-12620	RING	2021	23B-22-11350	WASHER
1984	23B-15-12640	RING	2022	23B-22-11410	COVER
1985	23B-15-12670	GEAR	2023	23B-22-11590	WASHER
1986	23B-15-12721	PISTON	2024	23B-22-21100	BEVEL GEAR
1987	23B-15-12730	PISTON	2025	23B-22-21190	BUSHING
1988	23B-15-12750	PISTON	2026	23B-22-21460	JOINT
1989	23B-15-12760	PISTON	2027	23B-22-31300	BEVEL GEAR ASSY
1990	23B-15-12761	PISTON	2028	23B-22-31530	FLANGE
1991	23B-15-12762	PISTON	2029	23B-22-31540	FLANGE
1992	23B-15-12771	PISTON	2030	23B-22-31550	CARRIER
1993	23B-15-12780	PISTON	2031	23B-22-31560	SPROCKET
1994	23B-15-13131	CAGE	2032	23B-22-31601	CASE ASSY DIFFERENTIAL
1995	23B-15-13180	FLANGE	2033	23B-22-31611	CASE
1996	23B-15-13211	GEAR	2034	23B-22-31621	CASE
1997	23B-15-13221	GEAR	2035	23B-22-31630	CAGE
1998	23B-15-13230	GEAR	2036	23B-22-31640	CAGE L.H
1999	23B-15-13311	SHAFT	2037	23B-22-31651	CAGE R.H
2000	23B-15-13610	COLLAR	2038	23B-22-31661	GEAR
2001	23B-15-18220	SHAFT	2039	23B-22-31670	GEAR
2002	23B-15-18410	SPACER	2040	23B-22-31680	GEAR
2003	23B-15-18420	SPACER	2041	23B-22-31690	BUSHING
2004	23B-15-22510	PIN	2042	23B-22-31721	PISTON
2005	23B-20-11200	SHAFT ASSY.	2043	23B-22-31840	SHAFT
2006	23B-20-11220	SHAFT ASSY.	2044	23B-22-31850	GEAR
2007	23B-20-31100	DRIVE SHAFT ASSY	2045	23B-22-31860	GEAR
2008	23B-20-31110	SHAFT ASSY YOKE	2046	23B-22-31880	PIN
2009	23B-22-05010	KIT	2047	23B-22-31890	PIN
2010	23B-22-11100	BEVEL GEAR	2048	23B-22-31910	SHAFT
2011	23B-22-11120	CASE	2049	23B-22-31930	SEAL
2012	23B-22-11130	FLANGE	2050	23B-22-31940	PLATE
2013	23B-22-11141	RETAINER	2051	23B-22-31950	WASHER
2014	23B-22-11190	CAGE	2052	23B-22-32113	COVER

KOMATSU PART LIST



2053	23B-22-61300	GEAR ASSY	2091	23B-27-11350	SHAFT
2054	23B-22-71190	BUSHING	2092	23B-27-11351	SHAFT
2055	23B-22-71600	CASE ASSY	2093	23B-27-11360	PLUG
2056	23B-22-71610	CASE	2094	23B-27-11370	COLLER
2057	23B-22-71620	CASE	2095	23B-27-11380	COLLER
2058	23B-22-71660	GEAR	2096	23B-27-11390	SPACER
2059	23B-22-71680	GEAR	2097	23B-27-11411	ROD
2060	23B-22-71930	SEAL	2098	23B-27-11441	ROD
2061	23B-22-71950	WASHER	2099	23B-27-11450	SPACER
2062	23B-23-05010	KIT	2100	23B-27-11460	JOINT
2063	23B-23-11130	CAGE	2101	23B-27-11480	SPACER
2064	23B-23-11190	SPROCKET	2102	23B-27-11520	PIM
2065	23B-23-21170	SPACER	2103	23B-27-11530	PIN
2066	23B-23-21300	CHAIN	2104	23B-27-11540	PIN
2067	23B-25-31131	SHAFT	2105	23B-27-11551	BALL
2068	23B-25-31132	SHAFT	2106	23B-27-11552	BALL
2069	23B-25-31171	GEAR	2107	23B-27-11553	BALL
2070	23B-25-31172	GEAR	2108	23B-27-11561	BALL
2071	23B-25-31431	SHAFT	2109	23B-27-11562	BALL
2072	23B-25-31432	SHAFT	2110	23B-27-11563	BALL
2073	23B-25-31450	SPROCKET	2111	23B-27-11610	BUSHNG
2074	23B-25-31500	CHAIN	2112	23B-27-11620	BUSHING
2075	23B-25-33121	PISTON	2113	23B-27-11630	BUSHING
2076	23B-27-11130	HUB	2114	23B-27-11640	WASHER
2077	23B-27-11141	HOUSING	2115	23B-27-11650	BOLT
2078	23B-27-11151	HOUSING	2116	23B-27-11660	PLUG
2079	23B-27-11160	BRACKET	2117	23B-27-11670	BUSHING
2080	23B-27-11170	SPACER	2118	23B-27-11680	BOLT
2081	23B-27-11180	CAP	2119	23B-27-11800	BUSHING
2082	23B-27-11190	HOLDER	2120	23B-27-11841	BOOT
2083	23B-27-11231	ROD	2121	23B-27-11860	SHIM
2084	23B-27-11250	PIM	2122	23B-27-11870	SHIM
2085	23B-27-11260	SPACER	2123	23B-27-11880	SHIM
2086	23B-27-11270	COVER	2124	23B-27-11890	LOCK
2087	23B-27-11281	BEARING	2125	23B-27-11910	RING
2088	23B-27-11310	PIM	2126	23B-27-11920	RING
2089	23B-27-11330	PIM	2127	23B-27-31130	HOUSING
2090	23B-27-11340	HOLDER	2128	23B-27-31140	HOUSING

2129	23B-27-31150	HOUSING	2167	23B-63-72102	CYLINDER ASSY.
2130	23B-27-31232	ROD LEANING	2168	23B-63-72121	ROD
2131	23B-27-31234	ROD LEANING	2169	23B-63-72140	CYLINDER
2132	23B-27-31410	ROD TIE	2170	23B-63-72302	CYLINDER ASS
2133	23B-27-31430	KIT	2171	23B-63-72320	ROD
2134	23B-27-31440	KIT	2172	23B-63-72321	ROD
2135	23B-27-31480	BUSHING	2173	23B-63-X1270	CYLINDER ASSY
2136	23B-27-31520	PIN	2174	23B-63-X1330	CYLINDER ASSY
2137	23B-27-31540	PIN	2175	23B-63-X1360	CYLINDER ASSY
2138	23B-27-31550	WASHER	2176	23B-63-Z1270	CYLINDER ASSY
2139	23B-27-31570	RING	2177	23B-63-Z1330	CYLINDER ASSY
2140	23B-27-31580	STUD BALL	2178	23B-63-Z1360	CYLINDER ASSY
2141	23B-27-31590	STUD BALL	2179	23B-70-11150	STUD
2142	23B-27-31680	KIT	2180	23B-70-11350	STUD
2143	23B-27-31690	KIT	2181	23B-70-12220	BLADE
2144	23B-27-31840	BOOT	2182	23B-70-13110	SUPPORT
2145	23B-32-11101	BRAKE SHOE ASSY	2183	23B-70-13111	SUPPORT
2146	23B-32-11102	BRAKE SHOE ASSY	2184	23B-70-13112	SUPPORT
2147	23B-32-31301	CALIPER ASSY PARKING BRAKE	2185	23B-70-14170	SHIM
2148	23B-32-31311	DISK	2186	23B-70-15150	WORM
2149	23B-32-31530	CARRIER	2187	23B-70-15151	WORM
2150	23B-32-31680	KIT	2188	23B-70-16210	SHIM
2151	23B-63-01310	CYLINDER ASS	2189	23B-70-16220	SHIM
2152	23B-63-18121	ROD	2190	23B-70-16240	SHIM
2153	23B-63-22101	CYLINDER	2191	23B-70-31140	BALL STUD
2154	23B-63-22102	CYLINDER	2192	23B-70-31331	GUIDE
2155	23B-63-22120	ROD	2193	23B-70-31451	SHIM
2156	234-63-22341	CYLINDER	2194	23B-70-31523	CAP
2157	23B-63-42101	CYLINDER	2195	23B-70-31540	SHIM
2158	23B-63-42102	CYLINDER ASSY.	2196	23B-70-31610	SHIM
2159	23B-63-42103	CYLINDER ASSY	2197	23B-70-31620	SHIM
2160	23B-63-42120	ROD	2198	23B-70-31630	PLATE
2161	23B-63-42140	CYLINDER	2199	23B-70-31640	PLATE
2162	23B-63-52102	CYLINDER	2200	23B-70-31680	PLATE
2163	23B-63-62101	CYLINDER	2201	23B-70-31730	BUSHING
2164	23B-63-62120	ROD	2202	23B-70-51550	GUIDE
2165	23B-63-62140	CYLINDER	2203	23B-70-51560	GUIDE
2166	23B-63-72101	STEERING	2204	23B-70-52121	WORM

KOMATSU PART LIST



2205	23B-70-52180	SHAFT	2243	381 897677-1	BEARING BALL
2206	23B-70-52282	GEAR	2244	381-921272-1	WASHER
2207	23B-70-52311	GEAR	2245	381-922549-1	PLATE SEPARATOR
2208	23B-70-71260	BRACKET	2246	381-922551-1	PLATE FRICTION
2209	23B-70-72190	BUSHING	2247	381-922984-1	WASHER
2210	23B-735-1170	ADJUSTER L.H.	2248	381-933780-1	GEAR ASSY
2211	23B-735-1180	ADJUSTER R.H.	2249	381-933781-1	BUSHING
2212	23B-735-1190	GUIDE	2250	381-933787-1	SHAFT
2213	23B-735-3151	BRACKET	2251	381 934207-1	RING
2214	23B-735-3240	ROD	2252	381 972679-1	RETAINER
2215	23B-735-3320	GUIDE	2253	381-977569-1	HOUSING
2216	23B-735-3321	GUIDE	2254	381-982918-1	CARRIER
2217	23B-735-3350	SHIM	2255	382-336593-1	SEGMAN
2218	23B-735-5132	ADJUSTER LH	2256	385-10178441	PISTON
2219	23B-735-5142	ADJUSTER RH	2257	385-10178471	PAD
2220	23B-735-5160	BRACKET	2258	385-10178472	PAD
2221	23C-27-51141	STUD BALL	2259	385-10178473	PAD
2222	23C-27-51152	STUD BALL	2260	385-10178474	PAD
2223	23C-70-51240	GUIDE	2261	417-01-11130	CUSHION
2224	23C-70-53140	GUIDE	2262	417-01-11131	CUSHION
2225	23C-70-53141	GUIDE	2263	417-06-23310	LAMP
2226	23S-15-12720	PLATE	2264	417-06-23320	LAMP
2227	23S-15-12730	PLATE	2265	417-06-23360	LAMP
2228	23S-15-12740	PLATE	2266	417-06-43110	LAMP
2229	23S-15-21140	PLATE	2267	417-20-12111	SHAFT ASSY.
2230	23S-15-21220	RING	2268	417-33-11122	PISTON
2231	23S-15-21270	PIM	2269	417-46-11151	PIN
2232	23S-15-21280	PIM	2270	418-01-11111	CUSHION
2233	23S-15-22240	GEAR	2271	418-03-48151	RADIATOR
2234	23S-15-22390	BUSHING	2272	418-20-14112	DRIVE SHAFT ASSY
2235	23S-15-22630	GEAR	2273	418-20-14650	YOKE
2236	23S-15-22631	RING GEAR	2274	418-22-36122	CABLE
2237	285-01-12411	RUBBER	2275	418-43-11140	CABLE
2238	287-01-18340	CUSHION	2276	418-43-16180	CABLE
2239	380 129509-1	RING	2277	419-03-11201	RADIATOR
2240	380-141131-1	BRAKE SHOE	2278	419-03-31112	RADIATOR
2241	380-197228-1	BEARING	2279	419-03-31114	RADIATOR
2242	380-223020-1	BUSHING	2280	419-03-48110	RADIATOR

2281	419-01-22160	MUFFLER	2319	419-43-16150	CABLE
2282	419-15-13071	YOKE	2320	419-43-16160	CABLE
2283	419-15-13533	COUPLING	2321	419-43-28110	CABLE
2284	419-15-14110	SHAFT	2322	419-46-11170	BUSHING
2285	419-15-14111	SHAFT	2323	419-46-11180	BEARING
2286	419-15-14140	SHAFT	2324	419-46-12270	BUSHING
2287	419-15-14150	GEAR 39 TEETH	2325	41B-22-12130	COVER
2288	419-15-14650	STRANIER	2326	41B-43-16180	CABLE
2289	419-20-12113	SHAFT ASS	2327	41K-13-11110	PRECLEANER
2290	419-20-12114	SHAFT ASS	2328	421-01-23120	BOWL
2291	419-20-12621	SPIDER	2329	421-03-21410	RADIATOR
2292	419-20-12650	SHAFT	2330	421-15-12360	WASHER
2293	419-20-12651	SHAFT	2331	421-15-12390	BUSHING
2294	419-20-13030	YOKE	2332	421-15-13270	COUPLING
2295	419-20-13512	COUPLING	2333	421-20-11650	YOKE
2296	419-20-13650	SHAFT	2334	421-20-12650	SHAFT
2297	419-20-14650	YOKE	2335	421-20-13030	COUPLING
2298	419-20-15112	FLANGE	2336	421-20-13532	COUPLING
2299	419-20-15113	FLANGE	2337	421-20-13540	DEFLECTOR
2300	419-20-15114	FLANGE	2338	421-20-13650	SHAFT
2301	419-20-24110	SHAFT ASSY	2339	421-20-14650	SHAFT
2302	419-22-11201	GEAR ASSY	2340	421-20-15122	BEARING
2303	419-22-12411	SHAFT	2341	421-20-15123	BEARING
2304	419-22-12510	SHAFT	2342	421-20-34511	SHAFT ASSY.
2305	419-22-12570	WASHER	2343	421-20-34650	SHAFT
2306	419-22-16321	CABLE	2344	421-23-21240	COUPLING
2307	419-22-22720	SHAFT	2345	421-33-21811	SEAL
2308	419-22-22730	GEAR	2346	421-33-32123	PLATE
2309	419-22-22741	GEAR	2347	421-33-32262	PLATE
2310	419-22-22810	CARRIER	2348	421-56-21760	ARM,WIPER
2311	419-22-26130	CABLE	2349	421-56-21770	ARM,WIPER
2312	419-22-31602	BEVEL GEAR ASSY	2350	421-70-11251	BUSHING
2313	419-30-11630	JANT ORİNGİ	2351	421-70-11261	BUSHING
2314	419-33-11120	PISTON	2352	421-70-11272	BUSHING
2315	419-33-21720	PISTON	2353	421-70-11381	BUSHING
2316	419-43-11173	CABLE	2354	421-70-21240	BUSHING
2317	419-43-11260	CABLE	2355	423-03-21111	RADIATOR
2318	419-43-12160	CABLE	2356	423-03-41110	RADIATOR

KOMATSU PART LIST



2357	423-03-41111	RADIATOR	2395	569-15-32580	WASHER
2358	423-15-12441	GEAR	2396	569-15-32590	WASHER
2359	423-15-13250	COUPLING	2397	569-63-22880	BUSHING
2360	423-15-13251	COUPLING	2398	569-63-41202	CYLINDER ASS
2361	423-20-12651	SHAFT	2399	569-63-41203	CYLINDER ASS
2362	423-20-13030	COUPLING	2400	569-63-41241	CYL
2363	423-20-23650	SHAFT	2401	569-63-41322	ROD
2364	423-20-32111	DRIVE SHAFT	2402	600-181-4370	FILTER ELEM
2365	423-20-32651	YOKE	2403	600-181-4420	FILTER ELEM
2366	423-20-33651	YOKE AND SHAFT	2404	600-181-4740	HOOD
2367	423-20-34111	SHAFT	2405	600-181-4870	BODY
2368	423-20-34310	DRIVE SHAFT	2406	600-181-4950	HOOD
2369	423-23-11230	COUPLING	2407	600-181-5710	BODY
2370	423-43-18231	CABLE	2408	600-652-1111	OIL COOLER
2371	423-43-18240	CABLE	2409	600-813-4650	STARTER
2372	423-43-28130	CABLE	2410	600-813-4812	STARTER
2373	424-02-21310	MUFFLER	2411	600-815-9260	
2374	424-02-21410	PIPE	2412	600-861-9120	ALTERNTOR
2375	424-03-11202	RADIATOR	2413	600-863-5130	MOTOR
2376	424-03-41111	RADIATOR	2414	6110-51-6340	RING
2377	424-15-11130	HOUSING	2415	6110-63-2110	OIL COOLER
2378	424-15-12741	PISTON	2416	6114-61-2100	OIL COOLER
2379	424-15-12750	PISTON	2417	6115-11-5311	MUFFLER
2380	424-15-12760	PISTON	2418	6124-61-1312	SHAFT WATER PUMP
2381	424-15-12771	PISTON	2419	6124-61-1332	IMPELLER
2382	424-15-12781	PISTON	2420	6124-61-1333	IMPELLER WATER PUMP
2383	424-20-12650	SHAFT	2421	6127-11-4580	HOOD
2384	424-20-13650	SHAFT	2422	6127-11-5113	EX MANIFOLD FRONT
2385	424-20-14650	YOKE	2423	6127-11-5132	EX MANIFOLD REAR
2386	424-22-11281	YOKE	2424	6127-11-5150	RING EXHAUST
2387	424-22-12541	GEAR	2425	6127-11-5330	EXHAUST MANIFOLD
2388	424-43-11222	CABLE	2426	6127-11-5331	EXHAUST MANIFOLD
2389	425-01-11110	PAD	2427	6127-11-5332	EXHAUST MANIFOLD
2390	561-43-41210	CABLE	2428	6127-11-5380	PIPE
2391	561-88-48950	BOLT	2429	6127-11-5421	MUFFLER
2392	562-15-11570	ASSM	2430	6127-11-5424	PIPE
2393	562-15-12571	WASHER	2431	6127-11-5425	PIPE
2394	569-03-41211	RADIATOR	2432	6127-11-5440	FLANGE

2433	6127-11-5460	COUPLING	2471	6127-71-5133	FUEL LINE SET
2434	6127-11-5472	BRACKET	2472	6127-71-5143	FUEL LINE SET
2435	6127-11-5704	MUFFLER ASSY	2473	6127-71-5171	FUEL LINE SET
2436	6127-11-5721	MUFFLER	2474	6127-71-5181	FUEL LINE SET
2437	6127-11-5881	PIPE	2475	6127-71-5191	FUEL LINE SET
2438	6127-11-5931	CAP	2476	6127-71-6211	BRACKET
2439	6127-11-5932	CAP	2477	6127-71-6212	BRACKET
2440	6127-11-8111	COVER	2478	6128-11-5112	EX MANIFOLD FRONT
2441	6127-11-8112	COVER CYL.BLOCK	2479	6128-11-5113	EX MANIFOLD FRONT
2442	6127-11-8121	COVER CYL.BLOCK	2480	6128-11-5131	EX MANIFOLD FRONT
2443	6127-11-8122	COVER	2481	6128-11-5132	EX MANIFOLD REAR
2444	6127-11-8211	BREATHER - PLS.	2482	6128-11-5133	MANIFOLD
2445	6127-21-1071	NOZZLE ASSY (MIN QTY 250 PCS)	2483	6128-11-5140	MANIFOLD CENTER
2446	6127-21-1440	NOZZLE	2484	6128-11-5141	EX MANIFOLD CENTER
2447	6127-21-1851	NOZZLE (MIN QTY 250 PCS)	2485	6128-11-5170	RAIN CAP
2448	6127-21-1861	NOZZLE (MIN QTY 250 PCS)	2486	6128-11-5303	CHECK VALVE
2449	6127-21-2412	SHAFT	2487	6128-11-5441	MANIFOLD
2450	6127-31-1190	SLEEVE	2488	6128-11-5562	MUFFLER
2451	6127-31-1293	SLEEVE	2489	6128-11-5571	PIPE
2452	6127-41-4410	SPRING	2490	6128-11-6141	MANIFOLD
2453	6127-41-4510	SEAT ENGINE SPRING	2491	6128-11-6142	MANIFOLD
2454	6127-41-4530	SEAT ENGINE SPRING	2492	6128-11-6210	WATER MANIFOLD
2455	6127-51-5413	COVER	2493	6128-11-6220	WATER MANIFOLD
2456	6127-51-6510	PIPE	2494	6128-11-6270	COLLAR
2457	6127-51-6631	CLAMP	2495	6128-11-6280	COLLAR
2458	6127-51-6810	VALVE	2496	6128-61-3044	PULLEY
2459	6127-51-7112	PIPE CAMSHAFT TUBE	2497	6128-61-3046	PULLEY
2460	6127-51-7121	PIPE CAMSHAFT TUBE	2498	6128-61-3531	PULLEY
2461	6127-51-7142	PIPE CAMSHAFT TUBE	2499	6136-61-1312	SHAFT IMPELLER
2462	6127-51-7232	PIPE CAMSHAFT TUBE	2500	6136-61-3610	COUPLING
2463	6127-61-1313	SHAFT / SAFT	2501	6136-71-3110	SHAFT
2464	6127-61-1332	IMPELLER	2502	6136-81-3112	AIR COMP-105 ENG
2465	6127-61-1333	FAN	2503	6137-11-5110	MANIFOLD
2466	6127-61-2113	COVER	2504	6137-11-5550	MUFFLER
2467	6127-61-3011	PULLEY	2505	6137-11-5610	MUFFLER
2468	6127-61-3531	PULLEY	2506	6137-11-5620	MUFFLER
2469	6127-61-3861	PULLEY	2507	6137-51-7620	TUBE
2470	6127-71-5123	FUEL LINE SET	2508	6137-51-7630	TUBE

KOMATSU PART LIST



2509	6138-11-4630	RADIATOR	2547	6207-11-5921	CLAMP
2510	6138-11-5530	MUFFLER	2548	6209-11-5211	MUFFLER
2511	6138-11-5550	MUFFLER	2549	6210-11-5232	CLAMP
2512	6138-11-5650	MUFFLER	2550	6210-81-3110	AIR COMP.140 ENG
2513	6138-51-6410	TUBE	2551	6210-81-3111	AIR COMP.140 ENG
2514	6138-61-1320	SHAFT IMPELLER	2552	6211-11-5140	MANIFOLD
2515	6138-61-1330	IMPELLER	2553	6211-11-5141	MANIFOLD
2516	6138-61-6120	PIPE	2554	6211-11-5150	MANIFOLD
2517	6138-81-3111	AIR COMP-105 ENG	2555	6211-11-5151	MANIFOLD
2518	6138-81-3112	AIR COMP.110 ENG	2556	6211-11-5152	MANIFOLD
2519	6150-11-5851	CLAMP	2557	6211-11-5160	MANIFOLD
2520	6150-21-5331	OIL GAUGE	2558	6211-11-5161	MANIFOLD
2521	6150-21-5650	GAUGE	2559	6211-12-5560	MUFFLER
2522	6150-31-1351	GEAR	2560	6215-81-3201	AIR COMP
2523	6151-11-4950	PIPE	2561	6217-21-5330	GAUGE
2524	6151-11-5110	MANIFOLD	2562	6221-11-5210	MUFFLER
2525	6151-11-5120	MANIFOLD	2563	6222-11-5410	MUFFLER
2526	6151-11-5130	MANIFOLD	2564	6222-11-5610	TUBE
2527	6151-11-5140	MANIFOLD	2565	6222-13-5412	MUFFLER
2528	6151-11-5150	MANIFOLD	2566	6222-13-5610	TUBE
2529	6151-11-5160	MANIFOLD	2567	6222-13-5622	CLAMP
2530	6151-11-5580	MUFFLER	2568	6251-11-5440	MUFFLER
2531	6151-11-5590	PIPE	2569	6261-21-5310	GAUGE
2532	6151-62-1310	SHAFT	2570	6261-81-1900	SENSOR
2533	6151-81-3112	AIR COMP.125 ENG	2571	6261-81-6901	SENSOR
2534	6151-11-5480	CLAMP	2572	6620-61-5300	OIL COOLER
2535	6151-11-5510	MUFFLER	2573	6678-11-5720	MUFFLER
2536	6151-11-5720	MUFFLER	2574	6679-11-5731	PIPE
2537	6151-13-5720	MUFFLER	2575	6678-11-5740	PIPE
2538	6152-12-5720	MUFFLER	2576	6685-61-9132	OIL COOLER
2539	6152-12-5850	CLAMP	2577	6685-81-7503	PRECLEANER
2540	6152-12-8531	MUFFLER	2578	6693-22-5302	OIL GAUGE
2541	6155-11-8710	MUFFLER	2579	6711-61-9102	OIL COOLER
2542	6156-11-5281	MUFFLER	2580	6711-61-9300	OIL COOLER
2543	6164-21-5401	GAGE	2581	6732-41-8410	TUBE
2544	6206-11-5440	MUFFLER	2582	6735-11-5530	MUFFLER
2545	6206-21-5370	GAUGE	2583	6742-01-2570	GAUGE
2546	6207-11-5631	TUBE	2584	6743-11-5230	CLAMP

2585	6743-11-5341	MUFFLER	2623	707-02-X7440	LIFT CYLINDER ASS
2586	6743-11-5710	TUBE	2624	707-02-X7450	LIFT CYLINDER ASS
2587	6743-11-5720	MUFFLER	2625	707-00-0E200	CYLINDER ASSY
2588	6743-21-5511	GAUGE	2626	707-00-0E201	CXYLINDER ASY
2589	6743-21-5610	OIL LEVEL	2627	707-00-0H040	CYLINDER ASSY
2590	6745-21-5110	GAUGE	2628	707-00-01350	CYLINDER ASSY
2591	6745-41-2151	PIN	2629	707-00-01380	CYLINDER
2592	6754-11-5210	MUFFLER	2630	707-00-01820	CYLINDER ASSY
2593	6754-21-5420	GAUGE	2631	707-00-01821	CYLINDER ASSY
2594	6754-72-1212	SENSOR	2632	707-00-07C70	CYLINDER ASSY
2595	707-00-00200	CYLINDER ASSY	2633	707-00-07C80	CYLINDER ASSY
2596	707-00-00210	CYLINDER ASSY	2634	707-00-07G00	CYLINDER
2597	707-00-0A260	CYLINDER ASSY	2635	707-00-07C30	CYLINDER ASSY
2598	707-02-00200	CYLINDER ASSY	2636	707-00-07G20	CYLINDER ASSY
2599	707-02-00220	CYLINDER ASSY	2637	707-00-07480	CYLINDER ASS
2600	707-02-00240	CYLINDER ASS	2638	707-00-07481	CYLINDER ASS
2601	707-02-00270	CYLINDER ASSY	2639	707-00-08E20	CYL ASS
2602	707-02-00271	CYLINDER ASSY	2640	707-00-08E30	CYLINDER
2603	707-02-00273	CYLINDER ASS	2641	707-00-08711	CYLINDER ASS
2604	707-02-00301	LIFT CYLINDER ASSY L.H	2642	707-00-08701	CYLINDER ASSY
2605	707-02-00311	LIFT CYLINDER ASSY R.H	2643	707-00-08731	CYLINDER ASSY
2606	707-02-00340	CYL ASSY	2644	707-00-08732	CYLINDER ASSY
2607	707-02-00380	CYLINDER ASSY	2645	707-00-0C140	CYLINDER
2608	707-02-00710	LIFT CYLINDER ASSY L.H	2646	707-00-0C150	CYLINDER ASSY
2609	707-02-00720	LIFT CYLINDER ASSY R.H	2647	707-00-0C160	CYLINDER ASSY
2610	707-02-00830	LIFT CYLINDER ASS	2648	707-00-0C170	CYLINDER
2611	707-02-X0380	CYLINDER ASS	2649	707-00-0C180	CYLINDER
2612	707-02-X0390	CYLINDER ASS	2650	707-00-0C200	CYL ASS
2613	707-02-X0220	CYLINDER ASS	2651	707-00-0C210	CYL ASS
2614	707-02-X0222	CYLINDER ASS	2652	707-00-0C220	CYLINDER
2615	707-02-X0230	CYLINDER AS	2653	707-00-0C240	CYLINDER ASS
2616	707-02-X0232	CYLINDER ASS	2654	707-00-0C671	CYLINDER ASS
2617	707-02-X0270	CYLINDER ASS	2655	707-00-0C681	CYLINDER ASS
2618	707-02-X0271	CYLINDER ASS	2656	707-00-0G890	CYLINDER ASSY
2619	707-02-X0280	CYLINDER ASS	2657	707-00-XG890	LEANING CYLINDER
2620	707-02-X0281	CYLINDER ASS	2658	707-00-0J430	CYLINDER ASSY
2621	707-02-X7150	LIFT CYLINDER ASS	2659	707-00-0J440	CYLINDER ASSY
2622	707-02-X7160	LIFT CYLINDER ASS	2660	707-00-0J450	CYLINDER ASSY

KOMATSU PART LIST



2661	707-00-0J470	CYLINDER ASS	2699	707-01-14130	CYLINDER ASSY
2662	707-00-0J540	BLADE LIFT CYLINDER	2700	707-01-14131	CYLINDER ASSY
2663	707-00-0U990	DRAWBAR SHIFT CYLINDER	2701	707-01-14140	CYLINDER ASSY
2664	707-00-XJ430	CYLINDER ASSY	2702	707-01-01070	CYLINDER ASSY
2665	707-00-XJ440	CYLINDER ASSY	2703	707-01-16081	CYLINDER ASS
2666	707-00-X7B30	CYLINDER ASSY	2704	707-01-16151	LIFT CYLINDER
2667	707-00-70131	CYLINDER ASSY	2705	707-01-20083	CYLINDER ASS
2668	707-00-90221	CYLINDER ASSY	2706	707-01-X2141	CYLINDER
2669	707-00-X7C40	CYLINDER GROUP, DRAWBAR SHIFT	2707	707-01-X2142	CYLINDER ASS
2670	707-00-X7C70	STEERING CYL	2708	707-01-XF170	CYLINDER ASS
2671	707-00-X7C80	STERING CYL	2709	707-01-XF171	CYLINDER ASS
2672	707-00-X7D50	CYLINDER ASS	2710	707-01-XF180	CYLINDER AS
2673	707-00-X7G10	CYLINDER	2711	707-01-XF181	CYLINDER ASS
2674	707-00-X7G30	CYLINDER	2712	707-01-X2150	CYLINDER ASS
2675	707-00-X7G20	CYLINDER ASS	2713	707-01-X2151	CYLINDER ASS
2676	707-00-X7G40	CYLINDER	2714	707-02-00140	CYLINDER ASS
2677	707-00-X7G50	CYLINDER ASSY	2715	707-02-00301	CYLINDER ASSY
2678	707-00-X7G60	CYLINDER ASSY	2716	707-02-00311	LIFT CYLINDER ASSY L.H
2679	707-00-X7G70	CYLINDER	2717	707-02-00660	LIFT CYLINDER ASSY R.H
2680	707-00-X7G80	CYLINDER ASS	2718	707-02-00670	CYLINDER ASSY
2681	707-00-X7G90	LEANING CYLINDER	2719	707-02-00100	CYLINDER ASSY
2682	707-00-XC150	CYLINDER ASS	2720	707-02-07030	BLADE LIFT CYLINDER
2683	707-00-XC170	ARTICULATE CYLINDER	2721	707-02-07040	CYLINDER ASSY L.H
2684	707-00-XC180	ARTICULATE CYLINDER	2722	707-02-X0140	CYLINDER ASSY R.H
2685	707-00-XC200	CYLINDER ASS	2723	707-02-X0150	BLADE LIFT CYLINDER
2686	707-00-XC210	CYLINDER ASS	2724	707-02-X7030	BLADE LIFT CYLINDER
2687	707-00-XC220	LEANING CYLINDER	2725	707-02-X7040	CYLINDER ASS
2688	707-00-XC240	LEANING CYLINDER	2726	707-02-X7310	CYLINDER ASS
2689	707-00-95120	CYLINDER ASS	2727	707-02-X7320	BLADE LIFT CYLINDER
2690	707-00-95130	CYLINDER ASS	2728	707-02-X7360	BLADE LIFT CYLINDER
2691	707-01-0A430	CYLINDER ASSY	2729	707-02-X7370	BLADE LIFT CYLINDER
2692	707-01-0C301	CYLINDER ASSY	2730	707-02-X7380	BLADE LIFT CYLINDER
2693	707-01-0F160	CYLINDER ASSY	2731	707-02-X7390	CYLINDER ASSY
2694	707-01-0F161	CYLINDER ASSY	2732	707-02-X7401	CYLINDER ASSY
2695	707-01-0F180	CYLINDER ASSY	2733	707-02-X7411	CYLINDER ASSY L.H
2696	707-01-0F181	CYLINDER ASSY	2734	707-02-X7860	CYLINDER ASSY L.H
2697	707-01-0K410	CYLINDER ASSY	2735	707-02-X7870	CYLINDER ASSY R.H
2698	707-01-0K420	TUBE	2736	707-04-00190	CYLINDER ASSY R.H

2737	707-11-13690	CYLINDER ASS	2775	707-27-14761	HEAD
2738	707-11-70130	CYLINDER	2776	707-27-14880	HEAD
2739	707-11-70180	CYLINDER	2777	707-27-16130	HEAD
2740	707-11-70190	CYLINDER	2778	707-27-16280	HEAD
2741	707-11-80C20	CYLINDER	2779	707-27-16490	HEAD
2742	707-11-80C30	CYLINDER	2780	707-27-16700	HEAD
2743	707-11-80C40	CYLINDER	2781	707-27-16840	HEAD
2744	707-11-80C50	CYLINDER	2782	707-27-18120	HEAD
2745	707-11-80K10	CYLINDER	2783	707-27-18520	HEAD
2746	707-11-80K20	CYLINDER	2784	707-27-18940	HEAD
2747	707-11-80J60	CYLINDER	2785	707-27-20540	HEAD
2748	707-11-80J70	CYLINDER	2786	707-27-20740	HEAD
2749	707-11-80J80	CYLINDER	2787	707-29-10900	HEAD
2750	707-11-80J90	CYLINDER	2788	707-29-11980	HEAD
2751	707-11-90120	CYLINDER	2789	707-29-12360	HEAD
2752	707-11-90320	CYLINDER	2790	707-29-12860	HEAD
2753	707-12-10171	CYLINDER	2791	707-29-13180	HEAD
2754	707-12-10181	CYLINDER L.H	2792	707-29-13630	HEAD
2755	707-12-11140	CYLINDER R.H	2793	707-29-50190	HEAD
2756	707-12-11150	CYLINDER	2794	707-29-50981	HEAD
2757	707-12-12140	CYLINDER	2795	707-29-70280	HEAD CYLINDER
2758	707-12-80090	CYLINDER	2796	707-29-70730	HEAD
2759	707-12-80160	CYLINDER	2797	707-29-70820	HEAD
2760	707-12-80220	CYLINDER	2798	707-29-70821	HEAD
2761	707-12-80230	CYLINDER	2799	707-29-70920	HEAD
2762	707-12-95010	CYLINDER	2800	707-29-70930	HEAD
2763	707-12-95020	CYLINDER	2801	707-29-70940	HEAD
2764	707-13-14130	CYLINDER	2802	707-29-80740	HEAD
2765	707-13-14131	CYLINDER	2803	707-29-80820	HEAD
2766	707-13-14630	CYLINDER	2804	707-29-80830	HEAD
2767	707-13-16141	CYLINDER	2805	707-29-80840	HEAD
2768	707-13-16150	CYLINDER	2806	707-29-80930	HEAD
2769	707-13-16250	CYLINDER	2807	707-29-90011	HEAD
2770	707-13-18370	ROD	2808	707-29-90480	HEAD
2771	707-13-20180	CYLINDER	2809	707-29-90540	HEAD
2772	707-13-20181	CYLINDER	2810	707-29-90930	HEAD
2773	707-13-20490	CYLINDER	2811	707-29-95240	HEAD
2774	707-27-14490	CYLINDER	2812	707-29-95730	HEAD

KOMATSU PART LIST



2813	707-29-95750	HEAD	2851	707-58-40J50	ROD PISTON
2814	707-36-14120	HEAD	2852	707-58-40J60	ROD
2815	707-36-16100	PISTON	2853	707-58-45130	ROD,PISTON
2816	707-36-16200	PISTON	2854	707-58-45240	ROD
2817	707-36-16400	PISTON	2855	707-58-50J00	ROD
2818	707-36-16410	PISTON	2856	707-58-50400	ROD,PISTON
2819	707-36-18060	PISTON	2857	707-58-50C30	ROD
2820	707-36-70160	PISTON	2858	707-58-50H00	ROD
2821	707-36-70930	PISTON	2859	707-59-40010	ROD PISTON
2822	707-36-14200	PISTON	2860	707-59-40090	ROD PISTON
2823	707-36-18400	PISTON	2861	707-59-80030	ROD
2824	707-36-20200	PISTON	2862	707-58-80051	ROD
2825	707-36-20600	PISTON	2863	707-60-45010	ROD
2826	707-36-22550	PISTON	2864	707-60-45020	PISTON
2827	707-36-25550	PISTON	2865	707-60-50020	ROD
2828	707-36-50180	PISTON	2866	707-60-65091	ROD
2829	707-36-50400	PISTON	2867	707-60-75070	ROD PISTON
2830	707-36-60910	PISTON	2868	707-60-80050	ROD PISTON
2831	707-36-61911	PISTON	2869	707-61-35040	ROD
2832	707-36-70280	PISTON	2870	707-61-35760	PISTON
2833	707-76-75030	PISTON	2871	707-66-70020	ROD
2834	707-36-70910	BUSHING	2872	707-66-75020	CAP
2835	707-36-70912	PISTON	2873	707-66-80040	CAP
2836	707-76-95050	PISTON	2874	707-67-20020	CAP
2837	707-36-80070	BUSHING	2875	707-67-27030	NUT
2838	707-36-80911	PISTON	2876	707-67-42010	NUT
2839	707-36-80920	PISTON	2877	707-67-52020	NUT
2840	707-36-80970	PISTON	2878	707-76-10130	NUT
2841	707-36-90180	PISTON	2879	707-76-10050	BUSHING
2842	707-36-90360	PISTON	2880	707-76-11050	BUSHING
2843	707-36-90911	PISTON	2881	707-76-11130	BUSHING
2844	707-36-90930	PISTON	2882	707-76-11290	BUSHING
2845	707-37-12010	PISTON	2883	707-76-11380	BUSHING
2846	707-37-95010	PISTON	2884	707-76-40020	BUSHING
2847	707-40-16010	PISTON	2885	707-76-42120	BUSHING
2848	707-52-90471	RETAINER	2886	707-76-45120	BUS
2849	707-58-10140	BUSHING	2887	707-76-50240	BUSHING
2850	707-58-11870	ROD	2888	707-76-80010	BUSHING

2889	707-76-80020	PISTON	2927	711-47-41141	GEAR
2890	707-76-80431	BUSHING	2928	711-47-41211	GEAR
2891	707-76-85140	BUSHING	2929	711-47-41252	CASE
2892	707-76-90130	BUSHING	2930	711-47-42521	PILOT
2893	707-76-90180	BUSHING	2931	711-47-51141	SHAFT
2894	707-76-90520	BUSHING	2932	711-47-52520	GEAR
2895	707-76-90530	BUSHING	2933	711-49-11141	SHAFT
2896	707-76-91050	BUSHING	2934	711-49-11170	GEAR
2897	707-76-95040	BUSHING	2935	711-49-12520	PLATE
2898	707-88-11290	BUSHING	2936	711-49-12540	SHAFT
2899	707-88-11300	SHIM	2937	711-49-14211	SLEEVE
2900	707-88-15010	SHIM	2938	711-49-14260	GEAR
2901	707-91-01140	SHIM	2939	711-49-14311	SHAFT
2902	707-91-01150	PISTON	2940	711-49-14360	GEAR
2903	711-14-11131	PISTON ASSY	2941	711-49-21190	PILOT
2904	711-14-11180	GEAR ASSY	2942	711-49-21210	CASE
2905	711-14-11210	GUIDE	2943	711-49-21250	CASE
2906	711-14-11251	CASE	2944	711-49-41250	PILOT
2907	711-14-11530	COVER	2945	711-50-41210	PILOT
2908	711-14-11651	BOSS	2946	711-50-41531	CASE
2909	711-14-11870	SHAFT	2947	711-52-11140	BOSS
2910	711-14-12511	COUPLING	2948	711-52-11210	RETAINER
2911	711-14-12521	SHAFT ASSY.	2949	711-52-11250	CASE
2912	711-14-12550	SHAFT	2950	711-52-11340	PILOT
2913	711-14-12561	BUSHING	2951	711-52-12530	GEAR
2914	711-20-31213	BUSHING	2952	711-52-12531	SLEEVE
2915	711-20-37213	CASE	2953	711-55-12520	SLEEVE
2916	711-47-00010	PISTON	2954	711-55-12522	SHAFT
2917	711-47-11140	SHAFT ASSY	2955	711-57-11190	SHAFT
2918	711-47-11770	RETAINER	2956	714-07-13151	GUIDE
2919	711-47-12520	PLATE	2957	714-07-13541	GEAR
2920	711-47-12530	SHAFT	2958	714-07-13711	GEAR
2921	711-47-31190	SLEEVE	2959	714-07-13730	SHAFT
2922	711-47-31211	GUIDE	2960	714-07-14102	GEAR
2923	711-47-31212	CASE	2961	714-07-14201	COUPLING
2924	711-47-31340	CASE	2962	714-07-14641	COUPLING
2925	711-47-31350	GEAR	2963	714-16-28320	STRANIER
2926	711-47-31351	GEAR	2964	714-17-12460	RETAINER

KOMATSU PART LIST



2965	714-23-14110	GEAR	3003	DK029622-8060	GASKET
2966	721-11-11401	COUPLING	3004	DK487003-3200	SEAL
2967	721-11-11501	CYLINDER	3005	DK487003-8120	COVER BEARING
2968	721-11-50360	CYLINDER	3006	DK487007-0400	COVER BEARING
2969	721-11-50470	CYLINDER	3007	DK487010-3320	ADAPTER
2970	721-11-50660	CYLINDER	3008	DK487012-0100	RING POST KIT
2971	721-11-70630	CYLINDER	3009	DK487012-0400	PIN-PISTON SNAP
2972	721-11-70690	CYLINDER	3010	DK487013-1820	PIN PISTON SNAP
2973	721-11-70900	CYLINDER	3011	DK487014-0600	CONNECTING ROD
2974	721-11-90370	CYLINDER	3012	DK487018-4320	METAL CRANK PIN
2975	721-11-90380	CYLINDER	3013	DK487020-0400	HEAD CYLINDER
2976	721-13-16160	CYLINDER	3014	DK487021-2020	FULL GASGET
2977	721-58-10150	CYLINDER	3015	DK487021-2420	ENGINE VALVE
2978	721-58-35310	ROD	3016	DK487027-1100	VALVE SPRING-INTAKE VALVE
2979	721-58-40920	ROD	3017	DK487028-1100	UNLOADER VALVE
2980	721-58-45780	ROD	3018	DK487028-1601	GUIDE
2981	721-58-50500	ROD	3019	DK487030-1420	VALVE
2982	721-58-70180	ROD	3020	DK487032-2700	GUIDE VALVE
2983	7834-41-3002	ROD	3021	KB 21011 30405	SPOOL
2984	7834-41-3003	MOTOR	3022	KB 21011 30417	SPOOL
2985	7861-93-2330	MOTOR	3023	KB 21011 31205	BRACKET
2986	8221-43-1110	SENSOR	3024	KB 21011 31702	PLATE
2987	8221-43-1111	CABLE	3025	KB B670A-00028	TILT CYL. FORKLIFT
2988	8A31-54-1110	CABLE	3026	KD0 231000-121	ARMATURE
2989	8A31-54-1130	CUSHION	3027	KD0 23740-0250	ELECTR
2990	8A31-54-1140	CUSHION	3028	KD0 23750-0250	ELECTR
2991	DK 487000-1200	CUSHION	3029	14X-06-11120	LAMP
2992	DK 487000-5800	HOUSING	3030	14X-12-11411	SHAFT
2993	DK 487001-2500	CASE CRANK	3031	14Y-21-13160	SEAL
2994	DK 487001-2700	LINER	3032	14X-21-13241	COLLAR
2995	DK 487008-5900	LINER	3033	14Y-21-23150	FLANGE
2996	DK 487008-8300-01	CRANK SHAFT	3034	14Y-22-13170	SPRING
2997	DK 487013-0920	CRANK SHAFT	3035	14Y-22-22110	CARRIER
2998	DK 487018-2020	CON ROD	3036	14Y-22-22150	GEAR
2999	DK 487018-4420	HEAD CYLINDER	3037	14Y-22-22370	BUSHING
3000	DK 487021-2420	HEAD CYLINDER	3038	14Y-22-24111	HUB
3001	DK 487030-1420	VALVE	3039	14Y-22-23121	HUB
3002	DK029333-8020	VALVE	3040	14Y-22-24130	HUB


3041	14Y-22-31000	SHAFT
3042	14Y-22-24120	SHAFT
3043	14Y-22-24190	SPACER
3044	14Y-27-11412	PINION SHAFT
3045	14Y-27-31150	COVER HUB
3046	14Y-27-31160	COVER HUB
3047	14Y-30-26130	GUARD
3048	14Y-30-26140	GUARD
3049	14Y-30-26210	GUARD
3050	14Y-30-26220	GUARD
3051	14Z-12-31310	COUPLING
3052	195-15-12270	GEAR
3053	195-15-12550	WASHER
3054	195-15-12552	WASHER
3055	195-15-12572	PIN
3056	195-15-12910	WASHER
3057	232-25-51170	ORING
3058	23B-22-31980	COLLAR
3059	23B-25-33111	CAGE
3060	23B-25-33132	BOLT
3061	23B-25-33150	ORING
3062	23B-25-33610	WASHER
3063	6136-31-1411	PULLEY
3064	6136-31-1511	PULLEY
3065	707-01-08621	CYLINDER ASS
3066	707-01-08622	CYLINDER ASS
3067	707-13-18281	CYLINDER
3068	707-59-95010	ROD PISTON
3069	707-59-90220	CYLINDER ASS
3070	714-12-17160	SPRING

CATERPILLAR PART LIST



1	1173356	BAR GP-EQUALIZER (D9R)	39	8P1865	BAR GP-EQUALIZER(D7G)
2	1409698	BAR GP-EQUALIZER (D8R)	40	9G0108	BAR GP-EQUALIZER (D11R/D11N)
3	1409699	BAR GP-EQUALIZER (D9R)	41	10R9156	BAR GP-EQUALIZER (D9R)
4	1409700	BAR GP-EQUALIZER (D10R/D10N)	42	10R9157	BAR GP-EQUALIZER (D9R)
5	1409701	BAR GP-EQUALIZER (D11R/D11N)	43	10R9158	BAR GP-EQUALIZER (D6R/D6H)
6	1414689	BAR GP-EQUALIZER (D7R)	44	10R9159	BAR GP-EQUALIZER (D11R/D11N)
7	1433332	BAR GP-EQUALIZER (D11R)	45	10R9160	BAR GP-EQUALIZER (D11R)
8	1723852	BAR GP-EQUALIZER (D10R/D10T)	46	20R0078	BAR GP-EQUALIZER(D6R/D6T)
9	1774651	BAR GP-EQUALIZER (D9R)	47	1125060	BRACKET
10	2012076	BAR GP EQUALIZER (D6R/D6H)	48	1125061	BRACKET
11	2012078	BAR GP-EQUALIZER (D6R)	49	1125575	CYLINDER
12	2072682	BAR GP-EQUALIZER(D10R/D10T)	50	1324929	CYLINDER
13	2072683	BAR GP-EQUALIZER (D11R/D11T)	51	1473309	AXLE
14	2072684	BAR GP-EQUALIZER (D11R)	52	2618553	PINION
15	2223676	BAR GP-EQUALIZER (D10T)	53	2S7099	HUB
16	2223682	BAR GP-EQUALIZER (D10R/D10T)	54	2527086	BRACKET
17	2226926	BAR GP-EQUALIZER (D8R/D8T)	55	3S7306	FLANGE
18	2313312	BAR GP-EQUALIZER (D6D)	56	4229841	SHAFT
19	2818488	BAR GP-EQUALIZER(D6R/D6T)	57	4229842	PINION
20	2818491	BAR GP-EQUALIZER(D6R/D6T)	58	5T2926	SHOE,CIRCLE GUIDE
21	3445381	BAR GP-EQUALIZER (D9R)	59	6G5532	SHAFT
22	3T2307	BAR GP-EQUALIZER(D10N/D10T)	60	6F7523	CAP
23	3T7785	BAR GP-EQUALIZER (D11R/D11T)	61	6J9256	TRUNNION
24	3W5979	BAR GP-EQUALIZER BAR (D6R/D6H)	62	6T1382	BOGIE
25	4M8874	BAR GP-EQUALIZER (D7G)	63	7J7488	BRACKET
26	4414771	BAR GP-EQUALIZER(D6R/D6T)	64	8W1751	BRACKET
27	4694661	BAR GP-EQUALIZER (D9N)	65	8W1752	BRACKET
28	7G0383	BAR GP-EQUALIZER (D11R/D11N)	66	8W1753	BRACKET
29	7G2224	BAR GP-EQUALIZER (D9R)	67	8W2761	MOLBOARD ASS
30	7G2613	BAR GP-EQUALIZER(D10R/D10T)	68	8W4066	BRACKET
31	7M0665	BAR GP-EQUALIZER (D6D)	69	8W4067	BRACKET
32	7T1854	BAR GP-EQUALIZER(D8R/D8T)	70	8W5092	PINION
33	8E0743	BAR GP-EQUALIZER (D5H)	71	9G0007	BOSS
34	8E0963	BAR GP-EQUALIZER (D5H)			
35	8E2842	BAR GP-EQUALIZER (D9R)			
36	8E4164	BAR GP-EQUALIZER (D9N)			
37	8E8789	BAR GP-EQUALIZER(D5H)			
38	8G4503	BAR GP-EQUALIZER (D5H)			

Exporting to countless countries



MTK®

SPARE PARTS OF EARTHMOVING MACHINES



Ostim OSB Mah. 1202/1 Cad. No: 89
Yenimahalle - Ankara / TURKEY



Phone: +90 312 395 16 96 (pbx)
Fax : +90 312 395 47 12



info@mtkmakina.com
www.mtkmakina.com



instagram.com/mtkmakina