

Isolator
Hlavní vypínač
Vypínač
Rozłącznik izolacyjny
Intrruptor
Hauptlastschalter
Interrupteur
Выключатель нагрузки
Заключаем в позицич OFF
Шалтер(товаров прекъсвач)
Rastavljač

NOARK

1


Mounting instructions
Montážní návod
Montážne inštrukcie
Instrukcja montazu
Instruçiuni de asamblare
Montageanweisung
Instructions de montage
Инструкция по монтажу
Monteringsanvisning
Istruzioni di montaggio
Instrucciones de montaje
Összeszerelési útmutató

Asennusohjeita
Montage-instructies
Instruções de montagem
Navodila za montažo
Οδηγίες Εγκατάστασης
Инструкции за инсталиране
Monteringsvejledningen
Montažu upute
Surinkimo instrukcijos
Instalēšanas instrukcijas
Скупштина упутство
Paigaldusjuhendid


2

Caution: Installation by electricians only
Varování: Montáž pouze osobou s elektrotech. kvalifikací
Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou
Uwaga: Montaż tylko przez uprawnionych instalatorów
Atenție: Instalare numai de catre electricieni
Vorsicht: Montagenur durch Elektrofachkräfte
Attention: Montage uniquement par un électricien
Осторожно: Монтаж только электрика


3







4



5



	1-35mm ²
	2-3.5Nm



NOARK



Printed with environment-friendly paper

Copyright Noark. All Rights Reserved

www.noark-electric.eu