

Consumer unit IP40
 Rozvodnice IP40
 Rozvodnica IP40
 Szafka IP40
 Cofreta compacte IP40
 Kleinverteiler IP40
 Coffret IP40
 Распределительная щитя IP40

Mounting instructions	Asennusohjeita
Montážní návod	Montage-instructies
Montážne inštrukcie	Instruções de montagem
Instrukcja montażu	Navodila za montažo
Instrucțiuni de asamblare	Οδηγίες Εγκατάστασης
Montageanweisung	Инструкции за инсталиране
Instructions de montage	Monteringsvejledningen
Инструкция по монтажу	Montažu upute
Monteringsanvisning	Surinkimo instrukcijos
Istruzioni di montaggio	Instalēšanas instrukcijas
Instrucciones de montaje	Скупштина упутство
Ősszeszerelési útmutató	Paigaldusjuhendid

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotech. kvalifikací

Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou

Uwaga: Montaż tylko przezu prawnionych instalatorów


Atenție: Instalare numai de catre electricieni

Vorsicht: Montagenur durch Elektrofachkräfte


Attention: Montage uniquement par un électricien

Осторожно: Монтаж только электрика

A



B



	A	B	C	D	E	P _{de}
PNS 8T/PNS 8W	236mm	215mm	112mm	107mm	108mm	14W
PNS 12T/PNS 12W	236mm	287mm	112mm	107mm	180mm	22W
PNS 18T/PNS 18W	236mm	396mm	112mm	107mm	289mm	22W
PNS 24T/PNS 24W	361mm	287mm	112mm	232mm	180mm	24W
PNS 2x18T/PNS 2x18W	361mm	396mm	112mm	232mm	289mm	26W
PNS 36T/PNS 36W	482mm	287mm	112mm	357mm	180mm	26W
PNS 48T/PNS 48W	653mm	287mm	112mm	482mm	180mm	28W
PNS 3x18T/PNS 3x18W	526mm	396mm	112mm	357mm	289mm	26W