



Enclosure
 Rozvodnice
 Rozvodnica
 Obudowa
 Carcasă
 Verteilerschrank
 Armoires électriques
 Шкаф
 Кутия
 Kucište
 Elosztó
 Spinta
 Sadalne
 Quadri
 Envolvente
 Bijlage

Mounting instruction
 Montážní návod
 Montážny návod
 Instrukcja montażu
 Instrucțiuni de asamblare
 Montageanweisung
 Instructions de montage
 Инструкция по монтажу
 Monteringsanvisning
 Istruzioni di montaggio
 Instrucciones de montaje
 Összeszerelési útmutató
 Asennusohjeita

Montage-instructies
 Instruções de montagem
 Navodila za montažo
 Οδηγίες Εγκατάστασης
 Инструкции за инсталиране
 Monteringsvejledningen
 Montažu upute
 Montavimo instrukcijos
 Instalēšanas instrukcijas
 Uputstvo za montažu
 Paigaldusjuhendid
 Інструкція з монтажу

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotechnickou kvalifikací

Varovanie: Montáž smie vykonávať iba osoba s elektrotechnickou kvalifikáciou

Uwaga: Montaż tylko przez uprawnionych instalatorów

Atentie: Instalare numai de catre electricieni

Vorsicht: Montage nur durch Eletrofachkräfte

Attention: Montage uniquement par un électricien

Осторожно: Установка данного оборудования производится только специалистом – электриком

Attenzione: L'installazione deve essere eseguita solamente da personale qualificato

Atención: Este dispositivo debe ser manipulado únicamente por personal cualificado

Figyelem: Szerelést kizárólag szakember végezheti


Внимание: Монтаж само от ел.специалисти

Dėmesio: montavimo darbus gali atlikti tik kvalifikuotas specialistas-elektrikas



Upozorenje: Montažu izvodi samo stručno lice

Обережно: монтаж виконує виключно електрик


A





B






C





D




Ea




Eb








F




EMF UMP
EMF HS




G




EMFS2




EMFS3




EMFS4





EMFS5




EMFS6




H



I





	(X)	(Y)	(Z)	(A)	(B)
EMFS2 48	566	489	137	566	440
EMFS3 72	566	630	137	566	581
EMFS4 96	566	771	137	566	722
EMFS5 120	566	912	137	566	863
EMFS6 144	566	1053	137	566	1004
EMFS2 66	730	489	137	730	440
EMFS3 99	730	630	137	730	581
EMFS4 132	730	771	137	730	722
EMFS5 165	730	912	137	730	863
EMFS6 198	730	1053	137	730	1004