

# GLOSSY ON GOOSE NECK




Wall lamp with reflector on gooseneck. The toggle switch is located on the bottom side of the base.

RP EUR incl. VAT

**R10543**

GLOSSY on a goose neck chrome 230V LED  
GU10 8W

**58,00**



 3D model

 manual

G11841

