


INSTALLATION MANUAL

38218E, 38236E, 38258E













Put the power cable through the cable entry in the housing, then screw down.




Put the brown power wire into L, the blue power into N, the yellow and green wire into ground terminal.











Warnings:

- 1. Make sure that the product is installed properly before connecting to electricity.
- 2. Do not cover the fitting.
- 3. Maintenance and installation should only be carried out by a professional electrician.

