


## **Installation instruction**


67117, 67118, 67117W, 67118W 67331, 67332, 67331W, 67332W




























## Switch:

Short press (> 50-600ms):	ON/OFF	
Long press (> 600ms):	Dim up/down A change in the light value deactivates lighting regulation only temporarily. As soon as the luminaire has been automatically switched on again (motion derection) or manually switched off and on again, regulation is activated again.	
2 x short press	The overwritten setpoint light calue is stored (luminaire acknowledges by flashing twice). Function is lockable via the DSI programmer.	

## Status LED on SENSOR:

STATUS	EVENT
-	Normal operation mode
Green flashing (2 s on, every 3 s)	Bright-out state active
One red flash	Motion detected
Two red flashes	Received infrared command
Three red flashes	Programmer communication running
Red flashing (1 s on, every 2 s)	PTM short circuit