



"X" means connect (ON)	position contact	0	1
		0°	60°
Yaming electric store 1 pole	1-2		X
	3-4		X
2 pole	5-6		X
	7-8		X