



Position 0

No power No working



Position 1

1-2 ,5-6 connected and working

Position 2

3-4,7-8 connected and working

		Switch internal on-off diagram		
X stands for pass	Position Contact	1	0	2
		45°	0°	45°
1 phase	1 — o — 2	X		
	3 — o — 4			X
2 phase	5 — o — 6	X		
	7 — o — 8			X

3 Position 8 Terminal
Universal Rotary selector
Latch Switch

