

# AGRIMAX ELOS

<b>TIRE SIZE</b>	<b>420/85 R 38</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	TRACTOR
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	144 A8/B



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	438	<b>RIM REC</b>	W 15 L
<b>OD (MM)</b>	1735	<b>RIM ALT</b>	W 13 ; W 14 L
<b>SLR (MM)</b>	785	<b>ECE</b>	E4-106R-000780
<b>RC (MM)</b>	5135	<b>SRI</b>	800

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6
50	1540	1795	2045	2300	2550	2800
40	1540	1795	2045	2300	2550	2800
30	1650	1920	2190	2460	2730	3000
10 LT	2070	2405	2745	3080	3420	3755
10 HT	1650	1920	2190	2460	2730	3000

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.