


# EARTHMAX SR 468

|                     |  |
|---------------------|--|
| <b>TIRE SIZE</b>    | <b>46/90 R 57</b>  |
| <b>UM</b>           | US STANDARD  |
| <b>CONSTRUCTION</b> |  RADIAL |
| <b>MACHINERY</b>    | САМОСВАЛ С ЖЕСТКОЙ РАМОЙ   |
| <b>VERSION</b>      | CUT RESISTANT COMPOUND   |
| <b>TIRE TYPE</b>    | TL   |
| <b>LI/SS</b>        | 252 B  |



## РАЗМЕРЫ US STANDARD

|                 |          |                    |           |
|-----------------|----------|--------------------|-----------|
| <b>USA CODE</b> | 94070589 | <b>RIM REC</b>     | 29.00/6.0 |
| <b>OD (IN)</b>  | 140.7    | <b>RIM ALT</b>     | 32.00/6.0 |
| <b>SLR (IN)</b> | 62.6     | <b>TRA CODE</b>    | E4        |
| <b>RC (IN)</b>  | 425.2    | <b>STAR RATING</b> | ★★        |

## LOAD CAPACITY (LBS/TIRE)

| MPH / PSI | 80     | 83     | 87     | 91     | 94     | 98     | 102    |
|-----------|--------|--------|--------|--------|--------|--------|--------|
| 30        | 117000 | 120000 | 123500 | 128000 | 132500 | 135500 | 139000 |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.