

## TR 135

|                  |                   |
|------------------|-------------------|
| <b>TIRE SIZE</b> | <b>14.9 - 24</b>  |
| <b>UM</b>        | IS STANDARD       |
| <b>MACHINERY</b> | TRACTOR / TRAILER |
| <b>VERSION</b>   | HD                |
| <b>TL/TT</b>     | TT                |
| <b>LI/SS</b>     | 135 A6            |



### DIMENSIONS IS STANDARD

|                 |             |                         |                 |
|-----------------|-------------|-------------------------|-----------------|
| <b>OD (MM)</b>  | 1265        | <b>ECE</b>              | E11-106R-007113 |
| <b>SLR (MM)</b> | 576         | <b>PR</b>               | 12              |
| <b>RC (MM)</b>  | 3837        | <b>SRI</b>              | 600             |
| <b>RIM REC</b>  | W 13        | <b>TRA CODE</b>         | R1              |
| <b>RIM ALT</b>  | W 12 ; W 11 | <b>TREAD DEPTH (MM)</b> | 36              |

### LOAD CAPACITY (KG/TIRE)

|                   |             |
|-------------------|-------------|
| <b>KM/H / BAR</b> | <b>2.60</b> |
| 30                | 2180        |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.