

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>300/95 R 46</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	148 D ; 151 A8



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	295	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1738	<b>RIM ALT</b>	W 10 ; W 11 ; DW 10 ; DW 11
<b>SLR (MM)</b>	812	<b>ECE</b>	E11-106R-0010269
<b>RC (MM)</b>	5318	<b>SRI</b>	825

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0
65	1105	1295	1670	2020	2240	2365	2585	2805	2995	3150
50	1160	1360	1755	2120	2355	2485	2715	2950	3145	3310
40	1210	1415	1830	2210	2450	2590	2830	3075	3280	3450
30	1270	1490	1925	2320	2575	2720	2975	3230	3445	3625
10	1655	1940	2505	3025	3355	3545	3875	4210	4490	4725

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.