

## TR 135

|                     |                                                                                        |
|---------------------|----------------------------------------------------------------------------------------|
| <b>TIRE SIZE</b>    | <b>12.4 - 20</b>                                                                       |
| <b>UM</b>           | IS STANDARD                                                                            |
| <b>CONSTRUCTION</b> |  BIAS |
| <b>MACHINERY</b>    | TRAKTOR / SLÄPVAGN                                                                     |
| <b>VERSION</b>      | STANDARD                                                                               |
| <b>TIRE TYPE</b>    | TT                                                                                     |
| <b>LI/SS</b>        | 116 A6                                                                                 |



### DIMENSIONER IS STANDARD

|                 |      |                |                     |
|-----------------|------|----------------|---------------------|
| <b>SW (MM)</b>  | 325  | <b>RIM REC</b> | W 11                |
| <b>OD (MM)</b>  | 1075 | <b>RIM ALT</b> | W 9 ; 9 ; W 10 ; 11 |
| <b>SLR (MM)</b> | 500  | <b>ECE</b>     | E4-106R-001965      |
| <b>RC (MM)</b>  | 3160 | <b>PR</b>      | 8                   |

### LOAD CAPACITY (KG/TIRE)

|                   |             |
|-------------------|-------------|
| <b>KM/H / BAR</b> | <b>2.10</b> |
| 30                | 1250        |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.