

## TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>18.4 - 38</b>   |
| <b>UM</b>        | US STANDARD        |
| <b>MACHINERY</b> | TRAKTOR / SLÄPVAGN |
| <b>VERSION</b>   | HD                 |
| <b>TIRE TYPE</b> | TT                 |
| <b>LI/SS</b>     | 139 A8             |



### DIMENSIONER US STANDARD

|                 |          |                |                 |
|-----------------|----------|----------------|-----------------|
| <b>USA CODE</b> | 94032211 | <b>RC (IN)</b> | 211.3           |
| <b>SW (IN)</b>  | 18.4     | <b>RIM REC</b> | W 16 L          |
| <b>OD (IN)</b>  | 68.9     | <b>RIM ALT</b> | W 15 L          |
| <b>SLR (IN)</b> | 31.3     | <b>ECE</b>     | E11-106R-004460 |

### LOAD CAPACITY (LBS/TIRE)

| <b>MPH / PSI</b> | <b>20</b> |
|------------------|-----------|
| 25               | 5360      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.