

# COMMANDER (R)

<b>TIRE SIZE</b>	<b>14.9 - 28</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	⊠ BIAS
<b>MACHINERY</b>	ERNTEMASCHINE / TRACTOR
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TT
<b>LI/SS</b>	130 A8



## ABMESSUNGEN US STANDARD

<b>USA-CODE</b>	94048021	<b>RC (IN)</b>	164.4
<b>SW (IN)</b>	15.3	<b>RIM REC</b>	W 13
<b>OD (IN)</b>	54.3	<b>RIM ALT</b>	W 11; W 12
<b>SLR (IN)</b>	25.3	<b>ECE</b>	E11-106R-005966

## LOAD CAPACITY (LBS/TIRE)

<b>MPH / PSI</b>	<b>33</b>
25	4180

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.