

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 44</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	142 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	275	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1632	<b>RIM ALT</b>	W 8 ; W 10
<b>SLR (MM)</b>	764	<b>ECE</b>	E4-106R-00784
<b>RC (MM)</b>	4983	<b>SRI</b>	775

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	1035	1355	1645	1805	1910	2095	2280	2465	2650	-
40	1035	1355	1645	1805	1910	2095	2280	2465	2650	-
30	1110	1450	1765	1935	2045	2245	2445	2645	2840	-
10	1235	1555	1910	2270	2625	2705	3025	3340	3660	3975

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.