


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 46</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	143 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	275	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1683	<b>RIM ALT</b>	W 8 ; W 10
<b>SLR (MM)</b>	792	<b>ECE</b>	E4-106R-000785
<b>RC (MM)</b>	5169	<b>SRI</b>	800

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	1120	1445	1745	1910	2045	2235	2430	2590	2725	-
40	1120	1445	1745	1910	2045	2235	2430	2590	2725	-
30	1200	1550	1870	2045	2190	2395	2600	2775	2920	-
10	1545	2000	2410	2640	2825	3090	3355	3580	3765	4090

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.