

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>340/85 R 48</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	151 D ; 154 A8



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	353	<b>RIM REC</b>	W 12
<b>OD (MM)</b>	1797	<b>RIM ALT</b>	W 11
<b>SLR (MM)</b>	855	<b>ECE</b>	E11-106R-005765
<b>RC (MM)</b>	5572	<b>SRI</b>	875

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	1.0	1.2	1.4	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
65	1485	1660	1865	2040	2245	2385	2625	2830	3005	3175	3450
50	1560	1740	1960	2140	2360	2505	2755	2975	3155	3335	3625
40	1615	1800	2025	2215	2440	2590	2850	3075	3265	3450	370
30	1710	1910	2145	2345	2585	2740	3020	3260	3455	3655	3970
10	2230	2485	2975	3055	3365	3575	3935	4245	4505	4765	5175

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.