

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>340/85 R 28</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	139 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	353	<b>RIM REC</b>	W 12
<b>OD (MM)</b>	1315	<b>RIM ALT</b>	W 11
<b>SLR (MM)</b>	603	<b>ECE</b>	E11-106R-008233
<b>RC (MM)</b>	3963	<b>SRI</b>	625

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6	2.0	2.4	2.8	3.2
50	950	1120	1290	1435	1605	1750	1920	2070	2260	2430
40	950	1120	1280	1435	1605	1750	1920	2070	2260	2430
30	1020	1200	1385	1540	1720	1880	2060	2215	2425	2605
10 LT	1275	1500	1730	1925	2155	2350	2580	2775	3035	3260
10 HT	1020	1200	1385	1540	1720	1880	2060	2215	2425	3490

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.