


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>340/85 R 48</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	152 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	353	<b>RIM REC</b>	W 12
<b>OD (MM)</b>	1797	<b>RIM ALT</b>	W 11
<b>SLR (MM)</b>	855	<b>ECE</b>	E4-106R-000800
<b>RC (MM)</b>	5572	<b>SRI</b>	875

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	1385	1815	2205	2415	2560	2805	3055	3305	3550	-
40	1385	1815	2205	2415	2560	2805	3055	3305	3550	-
30	1485	1940	2360	2585	2740	3005	3270	3535	3800	-
10	1655	2080	2560	3040	3515	3625	4050	4475	4900	5325

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.