


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 38</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	FELDSPRITZE / TRAUBENERNTEMASCHINE / ERNTEMASCHINE / LANDWIRTSCHAFTLICHE GERÄTE
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	140 A8/B



## ABMESSUNGEN IS STANDARD

<b>SW (MM)</b>	275	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1479	<b>RIM ALT</b>	W 8 ; W 10
<b>SLR (MM)</b>	697	<b>ECE</b>	E4-106R-000657
<b>RC (MM)</b>	4510	<b>SRI</b>	700

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	975	1275	1550	1700	1800	1975	2150	2325	2500	-
40	975	1275	1550	1700	1800	1975	2150	2325	2500	-
30	1045	1365	1660	1820	1930	2115	2305	2490	2675	-
10	1165	1465	1800	2140	2475	2550	2850	3150	3450	3750

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.