

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>460/85 R 34</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	147 A8/B



## DIMENSIONER US STANDARD

<b>USA CODE</b>	94021772	<b>RC (IN)</b>	191.5
<b>SW (IN)</b>	18.7	<b>RIM REC</b>	W 16 L
<b>OD (IN)</b>	64.8	<b>RIM ALT</b>	W 14 L; W 15 L
<b>SLR (IN)</b>	28.4	<b>ECE</b>	E4-106R-000632

## LOAD CAPACITY (LBS/TIRE)

MPH / PSI	9	12	15	17	20	23
30	3740	4340	4950	5570	6170	6780
25	3740	4340	4950	5570	6170	6780
20	4000	4650	5310	5960	6610	7260
5 LT	5000	5820	6650	7460	8280	9090
5 HT	4000	4650	5310	5960	6610	7260

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.