

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>520/85 R 46</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	173 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	516	<b>RIM REC</b>	DW 16 L ; W 16 A ; W 16 L ; DD 16
<b>OD (MM)</b>	2075	<b>RIM ALT</b>	DW 18 L ; W 18 L ; W 18 A
<b>SLR (MM)</b>	964	<b>ECE</b>	E4-106R-001494
<b>RC (MM)</b>	6310	<b>SRI</b>	975

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6	2.4	2.8	3.2	3.6	4.0
50	2340	2720	3105	3485	3870	4250	4875	5330	5785	6175	6500
40	2340	2720	3105	3485	3870	4250	4875	5330	5785	6175	6500
30	2505	2915	3325	3735	4145	4550	5215	5705	6190	6605	6955
10 LT	3135	3645	4160	4670	5185	5695	6535	7140	7750	8275	8710
10 HT	2505	2915	3325	3735	4145	4550	5215	5705	6190	6605	6955

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.