

## TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>11.2 - 24</b>   |
| <b>UM</b>        | US STANDARD        |
| <b>MACHINERY</b> | TRAKTOR / SLÄPVAGN |
| <b>VERSION</b>   | STANDARD           |
| <b>TIRE TYPE</b> | TT                 |
| <b>LI/SS</b>     | 106 A8             |



### DIMENSIONER US STANDARD

|                 |          |                                      |                 |
|-----------------|----------|--------------------------------------|-----------------|
| <b>USA CODE</b> | 94031177 | <b>RIM ALT</b>                       | W 9             |
| <b>OD (IN)</b>  | 43.5     | <b>ECE</b>                           | E11-106R-004623 |
| <b>SLR (IN)</b> | 20.4     | <b>PR</b>                            | 6               |
| <b>RC (IN)</b>  | 133.8    | <b>TRA CODE</b>                      | R1              |
| <b>RIM REC</b>  | W 10     | <b>TREAD DEPTH (32<sup>nd</sup>)</b> | 40.95           |

### LOAD CAPACITY (LBS/TIRE)

| <b>MPH / PSI</b> | <b>26</b> |
|------------------|-----------|
| 25               | 2090      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.