

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 36</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	139 A8/B



## DIMENSIONS US STANDARD

<b>USA CODE</b>	94027484	<b>RC (IN)</b>	170.7
<b>SW (IN)</b>	10.8	<b>RIM REC</b>	W 9
<b>OD (IN)</b>	56.2	<b>RIM ALT</b>	W 8 ; W 10
<b>SLR (IN)</b>	26.2	<b>ECE</b>	E4-106R-000659

## LOAD CAPACITY (LBS/TIRE)

MPH / PSI	12	17	23	29	35	41	46	52	58	64
30	2090	2730	3330	3650	3860	4230	4610	4980	5350	-
25	2090	2730	3330	3650	3860	4230	4610	4980	5350	-
20	2250	2930	3570	3910	4140	4540	4950	5350	5740	-
5	2490	3140	3860	4590	5310	5470	6120	6760	7400	8040

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.