


# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>460/85 R 38</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	149 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	475	<b>RIM REC</b>	W 16 L
<b>OD (MM)</b>	1747	<b>RIM ALT</b>	W 14 L ; W 15 L
<b>SLR (MM)</b>	785	<b>ECE</b>	E4-106R-000618
<b>RC (MM)</b>	5205	<b>SRI</b>	825

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6
50	1790	2080	2375	2665	2960	3250
40	1790	2080	2375	2665	2960	3250
30	1915	2230	2545	2855	3170	3480
10 LT	2400	2790	3180	3575	3965	4355
10 HT	1915	2230	2545	2855	3170	3480

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.