

# AGRIMAX SPARGO SB

<b>TIRE SIZE</b>	<b>VF 380/90 R 46</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	TRACTOR / SPRAYER
<b>VERSION</b>	STEEL BELTED
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	173 D



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	400	<b>RIM REC</b>	W13
<b>OD (MM)</b>	1852	<b>RIM ALT</b>	W12;DW13
<b>SLR (MM)</b>	856	<b>ECE</b>	E11-106R-0010176
<b>RC (MM)</b>	5668	<b>SRI</b>	875

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	1.0	1.2	1.4	1.6	1.8	2.0	2.2	2.4	2.6	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4
70	2545	2840	3195	3490	3670	3845	3965	4085	4290	4500	4675	4855	5000	5150	5295	5445	5680	5915
<b>FROM 65 TO 40</b>	2795	3120	3510	3835	4030	4225	4355	4485	4715	4940	5135	5330	5495	5655	5820	5980	6240	6500
30	2855	3185	3585	3915	4115	4310	4445	4575	4810	5040	5240	5440	5605	5770	5935	6100	6365	6630
20	2910	3245	3655	3990	4195	4395	4530	4665	4905	5140	5345	5545	5715	5885	6055	6220	6490	6760
10	3075	3435	3865	4220	4435	4650	4795	4935	5185	5435	5650	5865	6045	6225	6400	6580	6865	7150

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.