

# TR 144

<b>TYRE SIZE</b>	<b>8 - 18</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	⊠ BIAS
<b>MACHINERY</b>	TRACTOR
<b>VERSION</b>	STANDARD
<b>TYRE TYPE</b>	TT
<b>LI/SS</b>	90 A8



## DIMENSIONS US STANDARD

<b>USA CODE</b>	94004737	<b>RC (IN)</b>	98.8
<b>SW (IN)</b>	7.7	<b>RIM REC</b>	W 6
<b>OD (IN)</b>	33.1	<b>RIM ALT</b>	W 7; 5.50 F
<b>SLR (IN)</b>	15.2	<b>ECE</b>	E11-106R-006467

## LOAD CAPACITY (LBS/TYRE)

<b>MPH / PSI</b>	<b>28</b>
25	1325

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.