

## TR 135

|                     |                   |
|---------------------|-------------------|
| <b>TIRE SIZE</b>    | <b>13.6 - 28</b>  |
| <b>UM</b>           | US STANDARD       |
| <b>CONSTRUCTION</b> |                   |
| <b>MACHINERY</b>    | TRACTOR / TRAILER |
| <b>VERSION</b>      | STANDARD          |
| <b>TL/TT</b>        | TT                |
| <b>LI/SS</b>        | 133 A8            |



### DIMENSIONS US STANDARD

|                 |          |                |                |
|-----------------|----------|----------------|----------------|
| <b>USA CODE</b> | 94029976 | <b>RC (IN)</b> | 153.9          |
| <b>SW (IN)</b>  | 13.6     | <b>RIM REC</b> | W 12           |
| <b>OD (IN)</b>  | 51.6     | <b>RIM ALT</b> | W 11           |
| <b>SLR (IN)</b> | 23.9     | <b>ECE</b>     | E4-106R-002818 |

### LOAD CAPACITY (LBS/TIRE)

|                  |           |
|------------------|-----------|
| <b>MPH / PSI</b> | <b>52</b> |
| 25               | 4540      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.