


# EARTHMAX SR 33

|                     |  |
|---------------------|--|
| <b>TIRE SIZE</b>    | <b>395/85 R 20</b>   |
| <b>UM</b>           | US STANDARD  |
| <b>CONSTRUCTION</b> |  RADIAL |
| <b>MACHINERY</b>    | VEHÍCULO UNIVERSAL   |
| <b>VERSIÓN</b>      | STANDARD   |
| <b>TIRE TYPE</b>    | TL   |
| <b>LI/SS</b>        | 168 J  |



## DIMENSIONES US STANDARD

|                   |          |                |                 |
|-------------------|----------|----------------|-----------------|
| <b>CÓDIGO USA</b> | 94050611 | <b>RIM REC</b> | 10.00W          |
| <b>OD (IN)</b>    | 46.6     | <b>RIM ALT</b> | 10.00HF         |
| <b>SLR (IN)</b>   | 21.2     | <b>ECE</b>     | E11-54R-0017315 |
| <b>RC (IN)</b>    | 141.3    |                |                 |

## LOAD CAPACITY (LBS/TIRE)

|                  |            |
|------------------|------------|
| <b>MPH / PSI</b> | <b>125</b> |
| 62               | 12300      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.