



## DATA SHEET

Última  
actualización  
11-07-2026

# TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>12.4 - 38</b>   |
| <b>UM</b>        | US STANDARD        |
| <b>MACHINERY</b> | TRACTOR / REMOLQUE |
| <b>VERSIÓN</b>   | STANDARD           |
| <b>TIRE TYPE</b> | TL                 |
| <b>LI/SS</b>     | 135 A8             |



### DIMENSIONES US STANDARD

|                   |          |                |                 |
|-------------------|----------|----------------|-----------------|
| <b>CÓDIGO USA</b> | 94040704 | <b>RC (IN)</b> | 183.9           |
| <b>SW (IN)</b>    | 12.8     | <b>RIM REC</b> | W 11            |
| <b>OD (IN)</b>    | 60.0     | <b>RIM ALT</b> | W 9 ; W 10      |
| <b>SLR (IN)</b>   | 28.3     | <b>ECE</b>     | E11-106R-004454 |

### LOAD CAPACITY (LBS/TIRE)

|                  |           |
|------------------|-----------|
| <b>MPH / PSI</b> | <b>56</b> |
| 25               | 4800      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.