


# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>460/85 R 38</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	149 A8/B



## DIMENSIONER US STANDARD

<b>USA CODE</b>	94021789	<b>RC (IN)</b>	204.9
<b>SW (IN)</b>	18.7	<b>RIM REC</b>	W 16 L
<b>OD (IN)</b>	68.8	<b>RIM ALT</b>	W 14 L; W 15 L
<b>SLR (IN)</b>	30.9	<b>ECE</b>	E4-106R-000618

## LOAD CAPACITY (LBS/TIRE)

MPH / PSI	9	12	15	17	20	23
30	3950	4590	5240	5870	6530	7160
25	3950	4590	5240	5870	6530	7160
20	4220	4920	5610	6290	6990	7670
5 LT	5290	6150	7010	7880	8740	9600
5 HT	4220	4920	5610	6290	6990	7670

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.