

# AGRIMAX RT 955

<b>TIRE SIZE</b>	230/95 R 32
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	128 A8/B



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	228	<b>RIM REC</b>	W 7
<b>OD (MM)</b>	1251	<b>RIM ALT</b>	W 8
<b>SLR (MM)</b>	585	<b>ECE</b>	E4-106R-000764
<b>RC (MM)</b>	3810	<b>SRI</b>	600

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	705	920	1120	1225	1300	1425	1550	1675	1800	-
40	705	920	1120	1225	1300	1425	1550	1675	1800	-
30	755	985	1200	1315	1390	1525	1660	1795	1930	-
10	840	1055	1300	1540	1785	1840	2055	2270	2485	2700

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.