


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>230/95 R 48</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	FELDSPRITZE / TRAUBENERNTEMASCHINE / ERNTEMASCHINE / LANDWIRTSCHAFTLICHE GERÄTE
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	136 A8/B



## ABMESSUNGEN IS STANDARD

<b>SW (MM)</b>	228	<b>RIM REC</b>	W 7
<b>OD (MM)</b>	1656	<b>RIM ALT</b>	W 8
<b>SLR (MM)</b>	792	<b>ECE</b>	E4-106R-000778
<b>RC (MM)</b>	5085	<b>SRI</b>	800

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	875	1145	1390	1525	1615	1770	1930	2085	2240	-
40	875	1145	1390	1525	1615	1770	1930	2085	2240	-
30	940	1225	1490	1635	1730	1900	2065	2235	2400	-
10	1045	1315	1615	1920	2220	2285	2555	2825	3095	3360

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.