

# TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>14.9 - 28</b>   |
| <b>UM</b>        | US STANDARD        |
| <b>MACHINERY</b> | TRACTOR / ANHÄNGER |
| <b>VERSION</b>   | STANDARD           |
| <b>TIRE TYPE</b> | TT                 |
| <b>LI/SS</b>     | 121 A8             |



## ABMESSUNGEN US STANDARD

|                 |          |                |                 |
|-----------------|----------|----------------|-----------------|
| <b>USA-CODE</b> | 94031184 | <b>RC (IN)</b> | 164.2           |
| <b>SW (IN)</b>  | 14.9     | <b>RIM REC</b> | W 13            |
| <b>OD (IN)</b>  | 53.7     | <b>RIM ALT</b> | W 11 ; W 12     |
| <b>SLR (IN)</b> | 25.0     | <b>ECE</b>     | E11-106R-004626 |

## LOAD CAPACITY (LBS/TIRE)

|                  |           |
|------------------|-----------|
| <b>MPH / PSI</b> | <b>20</b> |
| 25               | 3200      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.