


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 46</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	143 A8/B



## DIMENSIONS US STANDARD

<b>USA CODE</b>	94042555	<b>RC (IN)</b>	203.5
<b>SW (IN)</b>	10.8	<b>RIM REC</b>	W 9
<b>OD (IN)</b>	66.3	<b>RIM ALT</b>	W 8 ; W 10
<b>SLR (IN)</b>	31.2	<b>ECE</b>	E4-106R-000785

## LOAD CAPACITY (LBS/TIRE)

MPH / PSI	12	17	23	29	35	41	46	52	58	64
30	2470	3190	3850	4210	4510	4930	5360	5710	6000	-
25	2470	3190	3850	4210	4510	4930	5360	5710	6000	-
20	2650	3420	4120	4510	4830	5280	5730	6120	6440	-
5	3410	4410	5310	5820	6230	6810	7400	7890	8300	9020

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.