


# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>420/85 R 28</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / TRAKTOR / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	139 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	438	<b>RIM REC</b>	W 15 L
<b>OD (MM)</b>	1425	<b>RIM ALT</b>	W 13 ; W 14 L
<b>SLR (MM)</b>	638	<b>ECE</b>	E4-106R-000602
<b>RC (MM)</b>	4241	<b>SRI</b>	675

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6
50	1340	1560	1775	1995	2215	2430
40	1340	1560	1775	1995	2215	2430
30	1435	1670	1905	2140	2375	2605
10 LT	1795	2090	2380	2675	2970	3260
10 HT	1435	1670	1905	2140	2375	2605

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.