

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>230/95 R 48</b>
<b>UM</b>	US STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	136 D ; 139 A8



## DIMENSIONS US STANDARD

<b>USA CODE</b>	94052837	<b>RC (IN)</b>	200.2
<b>SW (IN)</b>	9.0	<b>RIM REC</b>	W 7
<b>OD (IN)</b>	65.2	<b>RIM ALT</b>	W 8
<b>SLR (IN)</b>	31.2	<b>ECE</b>	E11-106R-004067

## LOAD CAPACITY (LBS/TIRE)

MPH / PSI	9	12	17	23	29	35	41	46	52	58
40	1730	2030	2620	3160	3520	3700	4060	4400	4700	4940
30	1820	2140	2760	3330	3690	3900	4270	4630	4940	5190
25	1880	2200	2840	3440	3810	4020	4400	4770	5090	5360
20	2000	2340	3020	3650	4050	4270	4670	5070	5410	5690
5	2600	3040	3940	4750	5270	5560	6080	6600	7040	7410

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.