

# AGRIMAX RT 855

<b>TIRE SIZE</b>	<b>460/85 R 34</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	
<b>MACHINERY</b>	SPRAYER / VINEYARD HARVESTER / TRACTOR / HARVESTER / IMPLEMENTS
<b>VERSION</b>	STANDARD
<b>TL/TT</b>	TL
<b>LI/SS</b>	158 A8/B



## DIMENSIONS IS STANDARD

<b>SW (MM)</b>	475	<b>RIM REC</b>	W 16 L
<b>OD (MM)</b>	1646	<b>RIM ALT</b>	W 14 L ; W 15 L
<b>SLR (MM)</b>	721	<b>ECE</b>	E11-106R-006759
<b>RC (MM)</b>	4865	<b>SRI</b>	775

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.6	0.8	1.0	1.2	1.4	1.6	2.0	2.4	2.8	3.2
50	1660	1955	2255	2510	2805	3060	3360	3615	3955	4250
40	1660	1955	2255	2510	2805	3060	3360	3615	3955	4250
30	1755	2095	2415	2685	3005	3280	3595	3870	4235	4550
10 LT	2225	2620	3020	3365	3760	4105	4500	4845	5300	5695
10 HT	1900	2245	2585	2875	3215	3510	3850	4140	4530	4870

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.