

# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>270/95 R 54</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	BESPRUTNINGSBIL / SKÖRDEMASKIN FÖR VINGÅRD / SKÖRDEMASKIN / ARBETSFORDON
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	146 A8/B



## DIMENSIONER IS STANDARD

<b>SW (MM)</b>	275	<b>RIM REC</b>	W 9
<b>OD (MM)</b>	1885	<b>RIM ALT</b>	W 8; W 10
<b>SLR (MM)</b>	894	<b>ECE</b>	E4-106R-001410
<b>RC (MM)</b>	5815	<b>SRI</b>	900

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	1170	1530	1860	2040	2160	2370	2580	2790	3000	-
40	1170	1530	1860	2040	2160	2370	2580	2790	3000	-
30	1255	1640	1995	2185	2315	2540	2765	2990	3210	-
10	1395	1755	2160	2565	2970	3060	3420	3780	4140	4500

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.