

## TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>14.9 - 28</b>   |
| <b>UM</b>        | IS STANDARD        |
| <b>MACHINERY</b> | TRACTOR / REMOLQUE |
| <b>VERSIÓN</b>   | STANDARD           |
| <b>TIRE TYPE</b> | TL                 |
| <b>LI/SS</b>     | 130 A6             |



### DIMENSIONES IS STANDARD

|                 |      |                |                |
|-----------------|------|----------------|----------------|
| <b>SW (MM)</b>  | 378  | <b>RIM REC</b> | W 13           |
| <b>OD (MM)</b>  | 1365 | <b>RIM ALT</b> | W 11 ; W 12    |
| <b>SLR (MM)</b> | 634  | <b>ECE</b>     | E4-106R-002744 |
| <b>RC (MM)</b>  | 4170 | <b>PR</b>      | 8              |

### LOAD CAPACITY (KG/TIRE)

| <b>KM/H / BAR</b> | <b>1.80</b> |
|-------------------|-------------|
| 30                | 1900        |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.