


# AGRIMAX RT 955

<b>TIRE SIZE</b>	<b>230/95 R 36</b>
<b>UM</b>	IS STANDARD
<b>CONSTRUCTION</b>	 RADIAL
<b>MACHINERY</b>	ОПРЫСКИВАТЕЛЬ / КОМБАЙН ДЛЯ УБОРКИ ВИНОГРАДА / КОМБАЙН / СЕЛЬСКОХОЗЯЙСТВЕННОЕ ОБОРУДОВАНИЕ
<b>VERSION</b>	STANDARD
<b>TIRE TYPE</b>	TL
<b>LI/SS</b>	130 A8/B



## РАЗМЕРЫ IS STANDARD

<b>SW (MM)</b>	228	<b>RIM REC</b>	W 7
<b>OD (MM)</b>	1352	<b>RIM ALT</b>	W 8
<b>SLR (MM)</b>	639	<b>ECE</b>	E4-106R-000765
<b>RC (MM)</b>	4112	<b>SRI</b>	650

## LOAD CAPACITY (KG/TIRE)

KM/H / BAR	0.8	1.2	1.6	2.0	2.4	2.8	3.2	3.6	4.0	4.4
50	745	970	1180	1295	1370	1505	1635	1770	1900	-
40	745	970	1180	1295	1370	1505	1635	1770	1900	-
30	795	1040	1265	1385	1470	1610	1755	1895	2035	-
10	885	1115	1370	1625	1885	1940	2170	2395	2625	2850

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.