

## TR 135

|                  |                   |
|------------------|-------------------|
| <b>TIRE SIZE</b> | <b>11.2 - 38</b>  |
| <b>UM</b>        | US STANDARD       |
| <b>MACHINERY</b> | TRACTOR / TRAILER |
| <b>VERSION</b>   | STANDARD          |
| <b>TL/TT</b>     | TL                |
| <b>LI/SS</b>     | 113 A8            |



### DIMENSIONS US STANDARD

|                 |          |                |                 |
|-----------------|----------|----------------|-----------------|
| <b>USA CODE</b> | 94070442 | <b>RC (IN)</b> | 173.6           |
| <b>SW (IN)</b>  | 11.2     | <b>RIM REC</b> | W 10            |
| <b>OD (IN)</b>  | 57.5     | <b>RIM ALT</b> | W 9             |
| <b>SLR (IN)</b> | 27.0     | <b>ECE</b>     | E11-106R-007700 |

### LOAD CAPACITY (LBS/TIRE)

|                  |           |
|------------------|-----------|
| <b>MPH / PSI</b> | <b>26</b> |
| 25               | 2540      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.