

# TR 135

|                  |                    |
|------------------|--------------------|
| <b>TIRE SIZE</b> | <b>18.4 - 34</b>   |
| <b>UM</b>        | US STANDARD        |
| <b>MACHINERY</b> | TRACTOR / ANHÄNGER |
| <b>VERSION</b>   | STANDARD           |
| <b>TIRE TYPE</b> | TT                 |
| <b>LI/SS</b>     | 137 A8             |



## ABMESSUNGEN US STANDARD

|                 |          |                |                |
|-----------------|----------|----------------|----------------|
| <b>USA-CODE</b> | 94003839 | <b>RC (IN)</b> | 197.2          |
| <b>SW (IN)</b>  | 18.4     | <b>RIM REC</b> | W 16 L         |
| <b>OD (IN)</b>  | 65.0     | <b>RIM ALT</b> | W 15 L         |
| <b>SLR (IN)</b> | 29.6     | <b>ECE</b>     | E4-106R-002716 |

## LOAD CAPACITY (LBS/TIRE)

| <b>MPH / PSI</b> | <b>20</b> |
|------------------|-----------|
| 25               | 5080      |

Rolling Circumference & SLR values are at rated Load and inflation pressure. These values may vary at different Load and pressure condition.